SUNX

PHOTOELECTRIC SENSOR

# DIGITAL FIBER SENSOR

FX-300 SERIES



# Constant advances achieving the highest level of performance in its class





# The FX-300 series of next-generation fiber sensors provides the highest level of sensing performance in its class


'Stable sensing', 'high sensing performance', 'easy operation', 'improved ease of maintenance' and 'preservation of the environment' are the five concepts underlying the new FX-300 series!



Downloaded from **Elcodis.com** electronic components distributor









# Stable sensing over long and short periods

In addition to a 'four-chemical emitting element' which suppresses changes in the light emitting element over time so that a stable level of light emission can be maintained over long periods, a 'APC (Åuto Power Control) circuit' has also been adopted afreshly. The light emitting amount can be controlled in minute degrees so that even changes occurring over very short periods can be handled, allowing stable sensing performance by suppressing deviations in light emitting amounts caused by changes in the ambient environment that could not previously be suppressed.




# Even greater sensing range FX-301/B/G/H FX-301-HS FX-305

Adoption of a 'double coupling lens' that increases emission efficiency to its maximum limits and greatly increases sensing range. Sensing ranges with small diameter fibers and ultra-small diameter fibers, which have become very popular due to the miniaturization of chip components, have been increased by 50 % over previous values achieved with other amplifiers.




Double coupling lens





# Light-emitting amount selection

If the light receiving level becomes saturated during closerange sensing or when sensing transparent or minute objects, you can adjust the light emitting amount of the sensor to stabilize sensing without needing to change the response time. Sensing that previously required the response time or fibers to be changed can now be set much more easily using this function.



# Large display 9999

Large display with 4 digits (9999). With a greater difference in digit value than previous models, threshold values can be set in units of 1 digit up to maximum 9999. Threshold setting can now be done more easily and accurately.



(During STDF, LONG and U-LG modes)

FX-301 FX-301-HS FX-305



Light emitting amount can be changed without changing response time

Digit difference comparison

Digit difference: Small Digit d

Example Digit difference between object A and object B


Previous models 4000


FX-305

FX-305

# Ultra high-speed 35 µs response


Ultra high-speed 35  $\mu$ s response. Even small objects moving at high speeds can be sensed. In addition, at 65  $\mu$ s the **FX-301** standard type is also twice as fast as previous models.





# Simplified systems using new operating modes

A window comparator mode and differential sensing mode have been added. These modes make it easy to carry out sensing tasks that previously required multiple sensors or involved complex threshold settings.




Equipped with 5 types timers

FX-305

The FX-305 includes the same ON-delay / OFF-delay / ONE-SHOT timer as the FX-301(-HS), as well as an ON-delay-OFF-delay timer and an ON-delay-ONE-SHOT timer. A wide variety of timer control operations can be carried out by these fiber sensors alone.

# Timer period: Output 1 0.5 to 9,999 ms (variable) Output 2 0.5 to 500 ms (variable)



# Multi-purpose 2-output

Single output is used, so that only one

cable is required, and no PLC processing is


required either.

Two independent output channels are provided, so that one sensor can be used for control tasks that previously required two sensors. In addition, the second output channel can be used for simple self-diagnosis and alarm output, so that ease of maintenance is improved.



Only the target objects are sensed.

No need to reset the sensitivity.




New Alarm output: Output 2 is set concurrently with output 1

FX-305


Drops in light amounts due to problems such as broken fibers or dirty tips are detected and output. When output 1 threshold value teaching is carried out with the **FX-305**, output 2 is set concurrently with the setting shifted by the amount of surplus.

Drops in surplus amounts of light intensity due to dust or other particles can therefore be detected and output.



In conjunction with teaching amount

Downloaded from Elcodis.com electronic components distributor




# Even beginners can quickly learn how to use the MODE NAVI

MODE NAVI uses six indicators to display the amplifier's basic operations. The current operating mode can be confirmed at a glance, so even a first time user can easily operate the amplifier without becoming confused.



# The use of only two switches makes for very simple operations FX-301/B/G/H FX-301-HS FX-305

Only two switches, the large jog switch and the large MODE key, are required for operation. Depressing the large MODE key sets the 'mode selection' and 'mode cancel' functions. The large jog switch is used to select from the detailed functions available within each mode, as well as to change numerical values after the mode has been chosen.



# Improved workability! Data bank switching and teaching can be carried out externally

The **FX-CH2** external input unit (optional) can be used to carry out teaching and data bank switching operations externally without needing to operate the digital fiber sensors directly. This greatly improves ease of workability

during setup.




# Easy confirming of threshold value settings FX-301 FX-301-HS FX-305

The threshold value can be confirmed by turning the jog switch even during RUN mode.



The threshold value is displayed

# Key lock function prevents accidental setting changes



This disables input from the jog switch and MODE key, thus preventing operators from accidentally changing settings.


# **Easy Maintenance**



# Communication unit improves equipment starting up and maintenance FX-301 FX-305




and data bank switching) to be carried out via a PLC, and also allows confirming of the incident light intensity an output status for the fiber sensors. This greatly improves workability during equipment starting up and maintenance.



# External input unit FX-CH2

Teaching and data bank switching for up to a maximum of 16 digital fiber sensors (FX-301 and FX-305) can be carried out all at once using an external device such as a PLC, touch screen or switch.



# Setup changes (external automatic teaching / data bank switching)

Digital fiber sensor settings can be changed using input from a touch screen or switch so that production line setup changes can be carried out more easily.

# External teaching

Full-auto teaching is recommended for teaching when the sensing object is changed without stopping the line.

# Data bank switching

Settings such as output operations (L-ON / D-ON) and timer operations can be recorded in the digital fiber sensor's data bank and switching can be carried out externally. \* Up to 3 files can be stored.

# FX-CH2 function list

# Teaching input

- The following types of external teaching can be carried out.
- Full-auto teaching
   Limit teaching '-'
   Limit teaching '+'
   2-level teaching

Data bank switching input Switching between 3 channels of data banks and loading and saving of all channels at once can be carried out.

# Key lock setting input

The key lock function that prevents incorrect operations by operators can be set on and off.


Main unit

Digital fiber sensor **FX-301**, **FX-305** power supply

FX-301 FX-305

# Product lineup

Connector for input device CN-EP1 [1 pc. included with FX-CH2(-P)]




# Wiring- and labor-saving design allows sideby-side configuration for up to sixteen units

FX-301/B/G/H FX-301-HS FX-305

# One unit can be used as either a main unit or sub unit

The amplifier unit can be used as either a main unit or a sub unit. This feature allows for easy mounting in the side-by-side configuration. The main and sub unit functions are distinguished only by the proper use of the main cable and the sub cable. Moreover, inventory management and maintenance is simplified.



# An optical communication function allows up to 16 sensors to be adjusted simultaneously

The optical communication function allows the data that is currently set to be copied and saved all at once for all amplifiers connected together from the right side. This greatly reduces troublesome setup tasks and makes setup much smoother. In addition, troublesome

adjustment operations at times such as when replacing sensors can also be carried out easily and data can also be copied and stored using the optical communication function.



Use the optical communication function for only the same types of sensors. Furthermore, the FX-301-HS is not equipped with optical communication function capability. Refer to p. 30 for details.

# Settings can be entered directly using numerical input


Every function can be directly set merely by the input of a four digit code (numbers) from the code table. This convenient feature is easy to set up. In the event that settings are accidentally changed at the operating site, merely entering the correct code can restore the original settings. This results in easy and quick maintenance.

First digit: Settings for response time and hysteresis Second digit: Settings for L/D ON and display mode










# Lead-free solder used is gentle on the environment *ECO*

SUNX promotes the use of lead-free materials in all of its sensor manufacturing processes including those used for the **FX-300** series of digital fiber sensors.

# Selectable cable length **ECO**

Made available are 3 lengths, 1 m 3.281 ft, 2 m 6.562 ft, and 5 m 16.404 ft, to suit your application requirements. This helps reduce the waste caused by cutting cables and lightens the installation workload.



# Reduced power consumption possible (ECO mode) < ECO

This turns off the digital display to reduce power consumption to approximately 600 W or less. (960 W is consumed when the display is on.)

# Environmentally friendly packaging <

With regard to effects on the environment, we only utilize the simplest of packaging methods greatly contributing to the reduction in wastes generated by your worksite. Also, the bags are made of polyethylene, a substance that doesn't give off polluting gases when burned.



Downloaded from Elcodis.com electronic components distributor


# FOR LCD • SEMICONDUCTOR INDUSTRY Guide to fibers and characteristics

# Improved stability over long and short periods

A four-chemical emitting element for stable sensing over long periods has been added, in addition to an APC (Auto Power Control) circuit that suppresses fluctuations in light amount over short periods.

The light amount becomes stable a short period after the power is turned on, so setup time can be reduced.


# Stable sensing comparison




# Mapping fiber

FT-KV1, FT-KV8, FR-KV1

This ultra-narrow optical beam fiber is ideal for mapping wafers.



W2 × H1.5 × D20 mm W0.079 × H0.059 × D0.787 in ultra-compact size allows this sensor to be installed even in thin 200 mm 7.874 in wafer handlers.



Aperture angle 2 ° FT-WKV8, FT-KV8 Aperture angle for the ultra-narrow optical beam is 2 ° or less. The light does not spread much at all, so that stable sensing can be obtained.



FX-301 FX-301-HS FX-305


**Retroreflective type FR-KV1** With a thickness of 2.3 mm 0.091 in, this fiber can be installed almost anywhere, and it is a retroreflective type so optical beam axis alignment is simple.

# Heat-resistant fiber

FT-H , FD-H


A variety of types are available, including a convergent reflective type for accurately sensing glass substrates, and a type with a bending radius of 10 mm 0.394 in that hardly takes up any space.

# IC detection within a high temperature handler




**Flexible type FT-H20W-M2** Withstands temperatures of + 200 °C + 392 °F and has a bending radius of 10 mm 0.394 in, this fiber can be installed almost anywhere.

# **Glass substrate detection**



Heat-resistant 350 °C + 662 °F FD-H35-M2 Can be used in temperatures ranging from -60 to +350 °C -76 to +662 °F. Stable sensing is obtained even at temperatures exceeding +300 °C +572 °F.

#### **Glass substrate detection**



Convergent reflective type FD-H30-L32, FD-H18-L31 Accurately senses glass substrates at high temperatures of + 300  $^\circ\text{C}$  + 572  $^\circ\text{F}.$ 

# FOR LCD • SEMICONDUCTOR INDUSTRY Guide to fibers and characteristics


# FOR LCD • SEMICONDUCTOR INDUSTRY

FX-305

# Large display 9999


Large display with 4 digits (9999).

Extremely fine settings for detecting minute changes can be made to provide more stable sensing for items such as transparent objects.




# Around liquids · Chemical-resistant fiber FT-Z802Y, FD-F705, FT-F902

Chemical-resistant fiber with fluorine resin coatings over the whole of the fiber, leak detection fiber that quickly sense leaks such as from detergents, and liquid detection fiber that accurately sense liquid levels are among the lineup of fibers that are ideal for liquid sensing.



Note: Use the FX-301-F amplifier that is specially designed for leak / liquid detection. For details, please refer to the 'sensor general catalog 2003-2004' or 'SUNX homepage' (http://www.sunx.co.jp/).




# Light emitting amount selection function

FX-301 FX-301-HS FX-305

When sensing transparent objects and minute objects, the light emitting amount can be changed without changing the response time, even for cases where the incident light intensity is fully saturated, which was not possible with conventional models. This allows stable sensing to be maintained, and there is no longer any need to change the sensing range or change the fiber sensor as used to be required.

Example: Sensing glass substrate



# FOR LCD • SEMICONDUCTOR INDUSTRY Guide to fibers and characteristics

# External data bank switching and teaching are possible External input unit FX-CH2

FX-301 FX-305


The **FX-CH2** external input unit (optional) can be used to carry out teaching and data bank switching operations externally without needing to operate the digital fiber sensors directly. This is ideal for locations such as clean rooms where entry and exit of personnel are restricted.

# Sensing glass substrate (stable sensing of minute differences)


When sensing transparent objects and extremely small objects, variations in the incident light intensity caused by external factors such as slippage of the beam axis due to vibration can result in incorrect operation.

In such cases, periodically setting limit teaching '-' can be used to ensure more stable sensing.

The **FX-CH2** can be used to carry out teaching externally, so that teaching can be carried out much more easily in places where entry and exit of personnel are restricted.



- ① Carry out limit teaching '-' before the sensing object (glass substrate) arrives (while there is no sensing object present). When the shift value is set to 5 % beforehand, the threshold value is set to a value that is at a level 5 % lower than the incident light intensity during teaching.
- ② Even when sensing glass substrates with high degrees of transparency (low damping), stable sensing is possible without changes in the light amount due to external causes.



# Upstream communication for reading data and teaching are also possible Upstream communication unit SC-GU1-485

A PLC or computer can be used for sending inputs (teaching or data bank switching) to the digital fiber sensors, and also a communication unit can be used for confirming incident light intensities and output statuses for the digital fiber sensors, which is ideal for equipment such as semiconductor manufacturing equipment in places where entry and exit of personnel are restricted.

The sensor settings and operation can be


Ideal for workplaces such as semiconductor

and LCD manufacturing lines where there are

restrictions on operators entering and exiting

improving ease of operation!

screen, greatly



<Touch screen monitor example>

Device A	monitor	enu <mark>&lt; Back</mark>
Line1 L	ine2 Line3 I	ine4
Tank A	Liquid level detection sensor 1 Liquid level detection sensor 2	<b>100 ()</b> <b>6000 ()</b>
Loader A	Passage confirmation sensor Mapping sensor	150 O


<Communicable commands>

Sensor incident light intensity
 Sensor settings verification

Sensor output status 
 Threshold value settings, etc.

# High general compatibility so that any type of PLC can be used RS-485 communication provides a high level of

RS-485 communication provides a high level of general compatibility so that any type of PLC can be used. Integration with existing systems is possible without the need to change PLCs.



Compatible with all PLCs equipped with RS-485 compatible units

#### Communication speed 57.6 kbps

High-speed communication at a maximum speed of 57.6 kbps allows the operator to instantly confirm information such as the incident light intensity and output statuses of the digital sensors.

Series connection of a maximum of 31 nodes is possible A maximum of 31 nodes can be connected in series. This is ideal for flexible handling when the sensors are to be installed in scattered locations or if more sensors are added.

#### Less wiring and installation work

Up to a maximum of 16 sensors can be connected side-by-side. Power can be supplied to all of them at once, so that less wiring and installation work is required. Wire-saving connectors also makes it possible to send output signals to the PLC in a single batch. FX-301-HS

# High-speed response 35 $\mu$ s


These digital fiber sensors have the fast response time of 35  $\mu$ s. They are ideal for sensing minute objects that are moving at high speeds.

# Independent dual outputs

#### FX-305

FX-305

Two independent output channels are provided, so that one sensor can be used for control tasks that previously required two sensors. In addition, the second output channel can be used for alarm output and error output, so that ease of maintenance is improved.



X A window comparator mode for distinguishing between sensing objects with single output is also available.

# Interference prevention up to maximum of sixteen units

**Ultra high-speed** 

response

Interference prevention can be set for up to a maximum of 16 units, so that they can be used with confidence in locations where the fibers are installed in contact with each other. In addition, interference prevention for two fibers can be set during 65  $\mu$ s ultra high-speed mode.

	Interference prevention switching function					
Mode		IP-1	IP-2			
	No. of units Response time		No. of units	Response time		
H-SP	2 units	65 µs	4 units	130 µs		
FAST	4 units	150 µs	8 units	300 µs		
STD	4 units	250 µs	8 units	500 μs		
STDF	4 units	700 µs	8 units	1.4 ms		
LONG	4 units	2.5 ms	8 units	5 ms		
U-LG	8 units	4.5 ms	16 units	9 ms		

For the FX-301/B/G/H, up to 4 units can be set.

The FX-301-HS is not equipped with an interference prevention function.


# FD-FM2 Dog

# Improved ease of working! External data bank switching and teaching

FX-301 FX-305

The **FX-CH2** external input unit (optional) can be used to carry out teaching and data bank switching operations externally without needing to operate the digital fiber sensors directly. This is very convenient for equipment which requires frequent setup changes.





FT-Z8


Detecting ICs in tranceparent stick

Parts feeder surplus detection

# **Retroreflective type fiber**

# FR-WKZ11, FR-KZ21/22

The lineup includes retroreflective type fibers which are ideal for sensing transparent objects.




# With polarizing filters FR-WKZ11

This fiber has a compact head of W9.5 $\times$ H5.2 $\times$ D15 mm W0.374 $\times$ H0.205 $\times$ D0.591 in. Equipped with allowable bending radius: R1 mm R0.039 in making it space efficient.

# Side-view fiber

# FT-V10


Because this is a side-view fiber, it is ideal for sensing in locations where space is scarce. Has a 4-side beveled shape and beam axis alignment with respect to the beveled surface is done when installing the product, so that the fiber can be installed easily just by aligning its surface.



# Chemical-resistant fiber


FT-Z802Y

With the case made of PFA (fluorine resin) and fiber sheath with PFA (fluorine resin), the fiber can be used with various types of chemical liquids.



# **Tough flexible fiber**

# FT-P81X, FD-P81X, FD-G6X



# **ORDER GUIDE**


Conne	ctor type amplifiers	Quick-conne	ction cable is no	ot supplied with the	amplifie	r. Please orde	r it separately.
Туре	Appearance	Model No.	Emitting element	Output	Q	uick-connectic	n cables
iypo			Emiliarity offernorit	ouput	Туре	Model No.	Length
		FX-301	Red LED	NPN open-collector transistor		CN-73-C1	1 m 3.281 ft
		FX-301P	Hed LED	PNP open-collector transistor	-core)		
		FX-301B		NPN open-collector transistor	able (3	CN-73-C2	2 m 6.562 ft
d type		FX-301BP	Blue LED	PNP open-collector transistor	Main cable (3-core)		
Standard type	- AVI	FX-301G		NPN open-collector transistor		CN-73-C5	5 m 16.404 ft
U)	MAL	FX-301GP	Green LED	PNP open-collector transistor		CN-71-C1	1 m 3.281 ft
		FX-301H	la facara d L ED	NPN open-collector transistor	-core)		
		FX-301HP	Infrared LED	PNP open-collector transistor	Sub cable (1-core)	CN-71-C2	2 m 6.562 ft
High-speed type		FX-301-HS		NPN open-collector transistor	Sub a		
High-s type		FX-301P-HS	Neu LED	PNP open-collector transistor		CN-71-C5	5 m 16.404 ft
		FX-305			core)	CN-74-C1	1 m 3.281 ft
				NPN open-collector transistor	Main cable (4-core)	CN-74-C2	2 m 6.562 ft
ction type			Red LED		Main	CN-74-C5	5 m 16.404 ft
High-function type	MAVI		Red LED		core)	CN-72-C1	1 m 3.281 ft
-		FX-305P		PNP open-collector transistor	Sub cable (2-core)	CN-72-C2	2 m 6.562 ft
					Sub c	CN-72-C5	5 m 16.404 ft

# **ORDER GUIDE**

# **Quick-connection cables**

# For FX-301(-HS)/B/G/H Quick-connection cable is not supplied with the amplifier. Please order it separately.

Туре	Model No.		Description		
	CN-73-C1	Length: 1 m 3.281 ft			
Main cable (3-core)	CN-73-C2	Length: 2 m 6.562 ft	0.15 mm <sup>2</sup> 3-core cabtyre cable, with connector on one end Cable outer diameter: $\phi$ 3.0 mm $\phi$ 0.118 in	In the second	
	CN-73-C5	Length: 5 m 16.404 ft		Sub cable	
	CN-71-C1	Length: 1 m 3.281 ft		• CN-71-C	
Sub cable (1-core)	CN-71-C2	Length: 2 m 6.562 ft	0.15 mm <sup>2</sup> 1-core cabtyre cable, with connector on one end Cable outer diameter: $\phi$ 3.0 mm $\phi$ 0.118 in		
	CN-71-C5	Length: 5 m 16.404 ft			



# For FX-305 Quick-connection cable is not supplied with the amplifier. Please order it separately.

	Туре	Model No.		Description	Main cable • CN-74-C
		CN-74-C1	Length: 1 m 3.281 ft		
	ain cable core)	CN-74-C2	Length: 2 m 6.562 ft	0.15 mm <sup>2</sup> 4-core cabtyre cable, with connector on one end Cable outer diameter: $\phi$ 3.0 mm $\phi$ 0.118 in	LA L
		CN-74-C5	Length: 5 m 16.404 ft		Sub cable
	Sub cable (2-core)	CN-72-C1	Length: 1 m 3.281 ft	0.15 mm <sup>2</sup> 2-core cabtyre cable, with connector on one end Cable outer diameter: $\phi$ 3.0 mm $\phi$ 0.118 in	• CN-72-C
		CN-72-C2	Length: 2 m 6.562 ft		
		CN-72-C5 Length: 5 m 16.404 ft			A CONTRACTOR OF A CONTRACTOR O

# End plates End plates are not supplied with the amplifier. Please order them separately when the amplifiers are mounted in cascade.

Appearance	Model No.	Description
	MS-DIN-E	When cascading multiple amplifiers, or when it moves depending on the way it is installed on a DIN rail, these end plates ensure that all amplifiers are mounted together in a secure and fully connected manner. Two pcs. per set

# **OPTIONS**


Designation	Model No.	Description
Amplifier mounting bracket	MS-DIN-2	Mounting bracket for amplifier
Fiber amplifier protective seal	FX-MB1	10 sets of 2 communication window seals and 1 connector seal Communication window seal: It prevents malfunction due to transmission signal from another amplifier, as well as, prevents effect on another amplifier. Connector seal: It prevents contact of any metal, etc., with the pins of the quick- connection cable.

# Amplifier mounting bracket



Fiber amplifier protective seal • FX-MB1







# **LIST OF FIBERS**

Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

pe	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2)	U-LG : FAST : LONG : H-SP : STDF : S-D : STD	Min. sensing object (Note 3)	Fiber cable length	Bending radius	Model N
	Lens mountable M4	1,600 62.992 1,100 43.307 700 27.559 530 20.866	400 15.748 200 7.874 180 7.087			R25 mm	FT-B8
	Lens mountable M4				<mark>⊁</mark> 2 m	R0.984 in	FT-FM2
	Sleeve 90 mm 3.543 in M4 ■ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	1,000 39.370 780 30.709 500 19.685 400 15.748	280 11.024 150 5.906 130 5.118			R0.984 in	FT-FM2S
M4	Sleeve 40 mm 1.575 in M4	M4 6.562 ft	Sleeve R10 mm R0.394 in	FT-FM2S			
2	Lens mountable M4	750 29.528 570 22.441 350 13.780 290 11.417	200 7.874 90 3.543 100 3.937			R1 mm R0.039 in	FT-W8
	Lens mountable M4 ■■☐☐■■ → ■■☐☐■■	900 35.433 650 25.591 400 15.748 320 12.598	230 9.055 100 3.937 110 4.331			R4 mm R0.157 in Flexible	FT-P80
	Lens mountable M4 ﷺ → ■ Tough flexible	900 35.433 650 25.591 380 14.961 320 12.598	230 9.055 100 3.937 110 4.331		1 m 3.281 ft	R10 mm R0.394 in	FT-P81X
	Lens mountable M4	550 21.654 400 15.748 250 9.843 190 7.480	140 5.512 70 2.756 80 3.150		<mark>≫</mark> 2 m 6.562 ft	R4 mm R0.157 in Flexible	FT-P60
Nut type	M4 ₩7 × H9 × D13.9 ₩0.276 × H0.354 × D0.547	750 29.528 570 22.441 350 13.780 290 11.417	200 7.874 90 3.543 100 3.937		~	R1 mm	FT-WR80
Nut	With lens M4 W7 × H9 × D14.6 W0.276 × H0.354 × D0.575	1,500 59.055 1,200 47.244 750 29.528 600 23.622	420 16.535 200 7.874 210 8.268		2 m 6.562 ft	R0.039 in	FT-WR80
Elbow	Lens mountable	740 29.134 530 20.866 320 12.598 230 9.055	150 5.906 75 2.953 80 3.150		2 m 6.562 ft	R25 mm R0.984 in	FT-R80
	Lens mountable (except FX-LE2) M3	1,000 39.370 780 30.709 500 19.685 400 15.748	280 11.024 150 5.906 130 5.118	$\phi$ 0.03 mm $\phi$ 0.0012 in opaque object		R25 mm	FT-T80
	M3 					R0.984 in	FT-NFM2
M3	Sleeve 90 mm 3.543 in M3	400 15.748 270 10.630 200 7.874 140 5.512	100 3.937 55 2.165 49 1.929		<mark>⊁</mark> 2 m	R0.984 in	FT-NFM2
2	Sleeve 40 mm 1.575 in M3				6.562 ft	Sleeve R10 mm R0.394 in	FT-NFM2
	<b></b>	220 8,661 160 6.299 100 3,937 80 3,150	55 2.165 25 0.984 28 1.102	¢0.02 mm ∳0.0008 in		<mark>R1 mm</mark> R0.039 in	FT-W4
	M3	350 13.780 250 9.843 150 5.906 100 3.937	75 2.953 30 1.181 35 1.378	opaque object		R4 mm R0.157 in Flexible	FT-P40
ong sensing ange	With lens M14	19,500 767.715 19,500 767.715 19,500 767.715 19,500 767.715 14,000 551.180	<mark>》</mark> 10,000 393.700 <b>№</b> 3,500 137.795 <b>№</b> 3,800 149.606	<pre>\$\$\phi 0.4 mm\$</pre>	<mark>≫</mark> 10 m 32.808 ft	R25 mm R0.984 in	FT-FI

Notes: 1) Refer to p.27 for the sensing ranges for the **FX-301-HS** in H-SP mode and for the **FX-301B/G/H**. 2) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut. 3) The minimum sensing object size is the value for red LED type. Please contact our office for information on the minimum sensing object size if using amplifiers other than red LED type. The optimum condition is the condition when the sensitivity is set so that the sensing output just changes to light incident operation in the object absent

condition.

# **LIST OF FIBERS**

Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

pe	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2)	■ : U-LG = : FAST = : LONG = : H-SP = : STDF = : S-D = : STD	Min. sensing object (Note 3)	Fiber cable length Sector	Bending radius	Model No
0.118	With lens · Long sensing range	1,500 59.055 1,200 47.244 750 29.528 600 23.622	420 16.535 200 7.874 210 8.268		<mark>≫</mark> 2 m	R1 mm R0.039 in	FT-WS8L
φ3 φ0.	¢3 ¢0.118	780 30.709 570 22.441 340 13.386 290 11.417	200 7.874 90 3.543 100 3.937	$\phi$ 0.05 mm $\phi$ 0.0020 in opaque object	6.562 ft	R0.039 III	FT-WS3
8	With lens $\cdot$ Long sensing range $\phi 2.5 \phi 0.098$	2,000 78,740 1,600 62.992 600 23.622 800 31,496	580 22.835 170 6.693 280 11.024			R25 mm	FT-SFM2I
2.5 <b>ø</b> 0.098	¢2.5 ¢0.098	1,000 39.370 780 30.709 500 19.685 400 15.748	280 11.024 150 5.906 130 5.118	¢0.03 mm ∳0.0012 in	≥ 2 m 6.562 ft	R0.984 in	FT-SFM2
φ2.	¢2.5 ¢0.098	750 29.528 570 22.441 350 13.780 290 11.417	200 7.874 90 3.543 100 3.937	opaque object		<mark>R1 mm</mark> R0.039 in	FT-WS8
0	<i>∳</i> 1.5 <i>∲</i> 0.059	400 15.748 270 10.630 200 7.874 140 5.512	100 3.937 55 2.165 49 1.929		~	R25 mm R0.984 in	FT-SNFM
φ1.5 φ0.059	¢1.5 ¢0.059	220 8.661 160 6.299 100 3.937 80 3.150	55 2.165 25 0.984 28 1.102	¢0.02 mm ∳0.0008 in	2 m 6.562 ft	R1 mm R0.039 in	FT-WS4
\$	φ1.5 φ0.059	350 13.780 280 11.024 160 6.299 120 4.724	90 3.543 40 1.575 42 1.654	opaque object	1 m 3.281 ft	R4 mm R0.157 in	FT-P2
¢ 1 ¢ 0.039	¢1 ¢0.039	100 3.937 80 3.150 50 1.969 40 1.575	30 1.181 13 0.512 17 0.669		500 mm 19.685 in	Flexible	FT-PS1
Ultra-small diameter	Beam diameter	20 0.787 18 0.709 13 0.512 10 0.394	8 0.315 3 0.118 3 0.118	¢0.02 mm	500 mm 19.685 in	R5 mm R0.197 in	FT-E12
Ultra-smal	Beam diameter $\phi 0.4 \phi 3$ $\phi 0.25 \text{ mm} \phi 0.016 \text{ in } \phi 0.016 \phi 0.118$ Sleeve part cannot be bent.	130 5.118 80 3.150 60 2.362 50 1.969	36 1.417 18 0.709 15 0.591		1 m 3.281 ft	R0.197 in	FT-E22
	↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	2,350 92.520 2,000 78.740 1,400 55.118 1,000 39.370	800 31.496 340 13.386 350 13.780	$\phi$ 0.05 mm $\phi$ 0.0020 in opaque object	×		FT-V10
	Sleeve part cannot be bent.	550 21.654 400 15.748 240 9.449 200 7.874	140 5.512 65 2.559 70 2.756		2 m 6.562 ft	R25 mm	FT-SFM2S
Side-view	Sleeve part cannot be bent.	410 16.142 390 15.354 220 8.661 180 7.087	125 4.921 60 2.362 63 2.480	¢0.02 mm ∳0.0008 in	1 m 3.281 ft	R0.984 in	FT-V22
0)	$ \begin{array}{c}                                     $	220 8.661 175 6.890 100 3.937 80 3.150	60 2.362 25 0.984 27 1.063	opaque object	*		FT-V41
		120 4.724 90 3.543	30 1.181 13 0.512 15 0.591		2 m 6.562 ft	R1 mm R0.039 in	FT-WV42

 Steteve part cannot be bent.
 40 1.575

 Notes: 1) Refer to p.27 for the sensing ranges for the FX-301-HS in H-SP mode and for the FX-301B/G/H.

 2) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.


 3) The minimum sensing object size is the value for red LED type. Please contact our office for information on the minimum sensing object size if using amplifiers other than red LED type.

 The optimum condition is the condition when the sensitivity is set so that the sensing output just changes to light incident operation in the object absent condition.



# LIST OF FIBERS

Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.



Notes: 1) Refer to p.27 for the sensing ranges for the **FX-301-HS** in H-SP mode and for the **FX-301B/G/H**. 2) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

3) The minimum sensing object size is the value for red LED type. Please contact our office for information on the minimum sensing object size if using amplifiers other than red LED type

The optimum condition is the condition when the sensitivity is set so that the sensing output just changes to light incident operation in the object absent condition

4) The fiber cable length practically limits the sensing range to 3,500 mm 137.795 in long.



# LIST OF FIBERS

ype	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2)	U-LG : FAST : LONG : H-SP : STDF : S-D : STD	Min. sensing object (Note 3)	Fiber cable length	Bending radius	Model No.
	350 °C 662 °F Lens mountable M4 ‱1 ∎00 ■ ■ ■00 ■ 10000	750 29.528 550 21.654	200 7.874 85 3.346	¢0.04 mm	2 m	R25 mm R0.984 in	FT-H35-M2
ant	350 °C 662 °F Sleeve 60 mm 2.362 in M4 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	330 12.992 280 11.024	90 3.543		6.562 ft	Fiber R25 mm R0.984 in Sleeve R10 mm R0.394 in	FT-H35-M2S
Heat-resistant	Allows flexible wiring 200 °C 392 °F Lens mountable ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲ ▲	420 16.535 310 12.205 180 7.087 140 5.512	100 3.937 40 1.575 50 1.969		1 m 3.281 ft	R10 mm R0.394 in	FT-H20W-M
Ĭ	200 °C 392 °F Lens mountable M4	750 29.528 550 21.654 320 12.598 280 11.024	200 7.874 85 3.346 90 3.543		1 m 3.281 ft	R25 mm	FT-H20-M1
	130 °C 266 °F Lens mountable ( <b>FX-LE2</b> only) M4	1,200 47.244 880 34.646 550 21.654 440 17.323	300 11.811 150 5.906 155 6.102	$\phi$ 0.06 mm $\phi$ 0.0024 in opaque object	≥ 2 m 6.562 ft	R0.984 in	FT-H13-FN
	Lens mountable (FX-LE1)				200 mm 7.874 in (Note 4)		FT-H20-J20 (Note 6)
. Ioint		530 20.866 390 15.354 225 8.858 200 7.874	140 5.512 60 2.362 60 2.362	$\phi$ 0.12 mm $\phi$ 0.005 in opaque object	300 mm 11.811 in (Note 4)	Heat-	FT-H20-J30 (Note 6)
Heat-resistant • . Ioint					500 mm 19.685 in (Note 4)	fiber R18 mm R0.709 in	FT-H20-J50 (Note 6)
Heat-	Γ <del>−−→</del> Π <i>φ</i> 3.8	840 33.071 550 21.654	200 7.874 90 3.543	¢0.16 mm ¢0.006 in	500 mm 19.685 in (Note 4)	(Note 5)	FT-H20-VJ5 (Note 6)
	∲0.150 ¢4 ¢0.157	370 14.567 280 11.024	90 3.543	opaque object			<b>FT-H20-VJ8</b> (Note 6)
resistant	Easy mounting $\cdot$ Rectangular head SEMI S2 compliant W7 × H15 × D13 W0.276 × H0.591 × D0.512	3,500 137.795 3,500 137.795 9,3,000 118,110 1,500 59.055	\$ 1,000 39.370 500 19.685 1530 20.866	$\phi 4 \text{ mm}$ $\phi 0.157 \text{ in}$ opaque object	<mark>≫</mark> 2 m 6.562 ft	R25 mm R0.984 in	FT-Z802Y
Chemical-resistant	¢5.5 ¢0.217	3,500 137.795 3,500 137.795 9,2,000 137.785 9,2,000 78.740 1,500 59.055	\$1,000 39.370 500 19.685 530 20.866	¢0.2 mm	<mark>≫</mark> 2 m	R30 mm	FT-L80Y
	Side-view \$5.5 \$\overline{0.217}	1,000 39.370 800 31.496 500 19.685 400 15.748	280 11.024 120 4.724 140 5.512		6.562 ft (Note 7)	R1.181 in	FT-V80Y
Vacuum-resistant	300 °C 572 °F Lens mountable (FV-LE1/SV2 only) M4 ₩4	350 13.780 250 9.843 150 5.906 125 4.921	90 3.543 50 1.969 40 1.575		1 m 3.281 ft		FT-H30-M1\ (Note 8)

Notes: 1) Please contact our office for the sensing ranges for the FX-301-HS in H-SP mode and for the FX-301B/G/H.

2) Please take care that the sening range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.
 3) The minimum sensing object size is the value for red LED type. Please contact our office for information on the minimum sensing object size if using

amplifiers other than red LED type.

The optimum condition is the condition when the sensitivity is set so that the sensing output just changes to light incident operation in the object absent condition. 4) This is the fiber length (fixed length) for heat-resistant fibers. The ordinary-temperature fibers are free-cut to 2 m 6.562 ft. 5) The ordinary-temperature fiber is R25 mm R0.984 in or more.

6) Heat-resistant joint fibers and ordinary-temperature fibers (FT-FM2) are sold as a set. Please refer to 'Heat-resistant joint fibers catalog' for details.

7) The allowable cutting range is 500 mm 19.685 in from the end that the amplifier inserted.
8) Sold as a set comprising vacuum type fiber + photo-terminal (FV-BR1) + fiber at atmospheric side (FT-J8). Please refer to 'Vacuum resistant fiber catalog' for details.

# Model No. when ordering heat-resistant joint fibers individually as replacement parts

- FT-H20-J30 (one pair set) • FT-H20-J50 (one pair set)
- FT-H20-J20 (one pair set) • FT-H20-VJ50 (one pair set)
- FT-H20-VJ80 (one pair set)

# Model No. when ordering vacuum-resistant fibers individually as replacement parts

- Vacuum-resistant fiber FT-H30-M1V (one pair set)
- Photo-terminal FV-BR1 (one pair set)
- · Fiber at atmospheric side FT-J8 (one pair set)



# LIST OF FIBERS

#### Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

The **FX-305** and **FX-301(-HS)** have different sensing modes.

FX-	305	/ FX-301 (Red LED		nd <b>FX-301(-HS</b> ) FAST, STD, STI				
Retr	ore	flective type		FX-301(-HS):	S-D, H-SP, FAST	, STD, LON	G (no <sup>`</sup> STD	F or U-LG mode)
Тур		Shape of fiber head (mm in)	Sensing range (mm in)(Note 2, 3)	STDE S-D	Min. sensing object (Note 4)		Bending radius	Model No.
Sharp bending	With polarizing filters	W9.5XH52XD15 W0.374XH0.205XD0.591 W30XH30XD0.5 W1.181XH1.181XD0.200	100 to 910 3.937 to 35.827 100 to 730 3.937 to 28.740 100 to 600 3.937 to 23.622 100 to 520 3.937 to 20.472	Cannot use Cannot use	$\phi$ 0.3 mm $\phi$ 0.012 in opaque object	2 m 6.562 ft	<mark>R1 mm</mark> R0.039 in	FR-WKZ11
beam	Top sensing	W85XH52XD21 W0.374XH0.205XD0827	200 7.874 200 7.874	200 7.874 200 7.874	Horizontal: $\phi$ 5.5 mm $\phi$ 0.217 in opaque object	*	R10 mm	FR-KZ21
Narrow	Side sensing	W9.5 X H25 X D52 W0.374 X H0.984 X D0.205 W0.417 X H1.102 X D0.398	200 7.874 200 7.874	200 7.874	Vertical: ¢0.06 mm ¢0.0024 in opaque object	2 m 6.562 ft	R0.394 in	FR-KZ21E
Wafer manning		W75XH22XD112W0295XH0.087XD0.441	15 to 370 0.591 to 14.567 15 to 330 0.591 to 12.992 15 to 240 0.591 to 9.449 15 to 210 0.591 to 8.268	15 to 170 0.591 to 6.693 15 to 80 0.591 to 3.150 15 to 90 0.591 to 3.543		<mark>≥2 m</mark> 6.562 ft	R10 mm R0.394 in	FR-KV1

FX-305 / FX-301 (Red LED type) sensing range (Note 1)

Notes: 1) Please contact our office for the sensing ranges for the FX-301-HS in H-SP mode and for the FX-301B/G/H.

2) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut. The sensing range of FR-WKZ11 is specified for the RF-13. The sensing range of FR-KZ21, FR-KZ21E and FR-KV1 is specified for the attached

reflector. 3) The sensing range of FR-WKZ11 is the possible setting range for the reflector or reflective tape. The fiber can detect an object less than 100 mm 3.937 in away.

However, note that if there are any white or highly-reflective surfaces near the fiber head, reflected incident light may affect the fiber head. If this occurs, adjust the threshold value of the amplifier unit before use.

The sensing range of FR-KZ21(E) is the possible setting range for the reflector. However, if setting the fiber to detect objects passing within 0 to 20 mm

to 0.787 in from the fiber head, unstable detection may result.
 The sensing range of FR-KV1 is the possible setting range for the reflector. The fiber can detect an object less than 15 mm 0.591 in away.
 4) The minimum sensing object size is the value for red LED type.

The optimum condition is the condition when the sensitivity is set so that the sensing output just changes to light incident operation in the object absent condition.

Ref	lecti	ive type 🛛 📶 🗊		FX-301(-HS):		, STD, LON	G (no <sup>`</sup> STD	F or U-LG mode)
Ту	pe	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2, 3)	■ : U-LG = : FAST : LONG = : H-SP = : STDF = : S-D = : STD	Min. sensing object (Note 4)	Fiber cable length Sector	Bending radius	Model No.
			600 23.622 480 18.898 280 11.024 220 8.661	160 6.299 85 3.346 75 2.953			R25 mm	FD-B8
			410 16.142 310 12.205 200 7.874 140 5.512	100 3.937 55 2.165 47 1.850	-	.02 mm .0008 in	R0.984 in	FD-FM2
		Sleeve 90 mm 3.543 in M6 \$\phi_2.5 \ntilde{0.098}\$	370 14.567 270 10.630	85 3.346 45 1.772			Fiber R25 mm R0.984 in Sleeve R10 mm R0.394 in	FD-FM2S
Threaded type	M6	Sleeve 40 mm 1.575 in M6 \$\phi 2.5 \not 0.098	170 6.693 110 4.331	39 1.535				FD-FM2S4
Thread			250 9.843 190 7.480 110 4.331 90 3.543	60 2.362 25 0.984 32 1.260			R1 mm R0.039 in	FD-W8
		M6	300 11.811 220 8.661 130 5.118 100 3.937	70 2.756 30 1.181 35 1.378			R4 mm R0.157 in Flexible	FD-P80
		M6	270 10.630 185 7.283 100 3.937 80 3.150	60 2.362 30 1.181 35 1.378		1 m 3.281 ft	R10 mm R0.394 in	FD-P81X
	Elbow		240 9.449 185 7.283 110 4.331 85 3.346	60 2.362 25 0.984 30 1.181		2 m 6.562 ft	R25 mm R0.984 in	FD-R80

Notes: 1) Refer to p.27 for the sensing ranges for the FX-301-HS in H-SP mode and for the FX-301B/G/H.
2) The sensing range is specified for white non-glossy paper [400 × 400 mm 15.748 × 15.748 in] as the object.
3) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

4) The minimum sensing object size is the value for red LED type at maximum sensitivity.

Note that the corresponding setting distance is different from the rated sensing distance.



# **LIST OF FIBERS**

# Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

ype	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2, 3)	■ : STDF ■ : ■ : STD	FAST H-SP S-D Diject (Note 4)	longth	Bending radius	Model No.
		370 14.567 1270 10.630 170 6.693 110 4.331	85 3.346 45 1.772 39 1.535			R25 mm	FD-T80
						R0.984 in	FD-NFM2
	Sleeve 90 mm 3.543 in M4 \$\phi 1.48 \nt 0.058	140 5.512 90 3.543 60 2.362 45 1.772	35 1.378 16 0.630 16 0.630			Fiber R25 mm R0.984 in	FD-NFM2S
	Sleeve 40 mm 1.575 in M4					Sleeve R10 mm R0.394 in	FD-NFM2
M4	Sleeve 40 mm 1.575 in M4 \$\$\phi1.48 \$\phi0.058\$	40 1.575 30 1.181 18 0.709 15 0.591	12 0.472 14.5 0.177 15 0.197	∳ 0.02 mm ∳ 0.0008 in gold wire	<mark>≫</mark> 2 m 6.562 ft	Fiber R1 mm R0.039 in Sleeve B10 mm	FD-W44
		250 9.843 190 7.480 110 4.331 90 3.543	60 2.362 25 0.984 32 1.260			R10 mm R0.394 in R1 mm R0.039 in	FD-WT8
	Coaxial · Lens mountable	85 3.346 65 2.559 37 1.457 32 1.260	25 0.984 10 0.394 11 0.433			R2 mm R0.079 in	FD-WG4
	M4	150 5.906 110 4.331 65 2.559 55 2.165	42 1.654 15 0.591 19 0.748			R25 mm R0.984 in	FD-G4
		130 5.118 90 3.543 55 2.165 45 1.772	30 1.181 13 0.512 16 0.630			R4 mm R0.157 in Flexible	FD-P60
	Small diameter	140 5.512 90 3.543 60 2.362 45 1.772	35 1.378 16 0.630 16 0.630			R25 mm R0.984 in	FD-T40
		40 1.575 30 1.181 18 0.709 15 0.591	12 0.472 4.5 0.177 5 0.197		×	<mark>R1 mm</mark> R0.039 in	FD-WT4
	M3	50 1.969 36 1.417 20 0.787 18 0.709	14 0.551 5.5 0.217 6 0.236	¢0.02 mm	2 m 6.562 ft	R4 mm R0.157 in Flexible	FD-P40
	Lens mountable (FX-MR3, FX-MR6) M3 Coaxial	150 5.906 110 4.331 65 2.559 55 2.165	42 1.654 15 0.591 19 0.748			R25 mm R0.984 in	FD-G6
M3	Lens mountable (FX-MR3, FX-MR6) M3 Coaxial Tough flexible	150 5.906 90 3.543 48 1.890 45 1.772	35 1.378 12 0.472 20 0.787			R10 mm R0.394 in	FD-G6X
Σ	Coaxial · Lens mountable (FX-MR3, FX-MR6) M3 cmm() High precision	50 1.969 38 1.496 25 0.984 18 0.709	14 0.551 5 0.197 6 0.236			R25 mm R0.984 in	FD-EG1
	Coaxial Lens mountable (FX-MR3, FX-MR6) M3 Light emitting fiber element High precision \$0.175 \$0.007	40 1.575 25 0.984 14 0.551 12 0.472	9 0.354 3 0.118 5 0.197	¢0.04 mm	500 mm	R10 mm	FD-EG2
	Coaxial · Lens mountable (FX-MR3, FX-MR6) M3 Light emitting fiber element High precision \$0.125 \$0.005	20 0.787 15 0.591 9 0.354	15 0.197 12.5 0.098 13 0.118	<pre></pre>	19.685 in	R0.394 in	FD-EG3
	M3	6.5 0.256 5 0.197 3 0.118	12 0.079 Cannot use Cannot use	¢0.02 mm		R25 mm	FD-EN500
	Coaxial $M3 \neq 0.8 \neq 0.031$	50 1.969 38 1.496 20 0.787	14 0.551 5 0.197 6 0.236	¢0.0008 in gold wire		R25 mm R0.984 in	FD-ENM1

Notes: 1) Refer to p.27 for the sensing ranges for the FX-301-HS in H-SP mode and for the FX-301B/G/H.
2) The sensing range is specified for white non-glossy paper [200 × 200 mm 7.874 × 7.874 in (FD-T80, FD-WT8: 400 × 400 mm 15.748 × 15.748 in, FD-W44, FD-WT4, FD-P40, FD-G6, FD-EG1, FD-EG2, FD-EG3, FD-EN500S1, FD-ENM1S1: 100 × 100 mm 3.937 × 3.937 in)] as the object.
3) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.
4) The minimum sensing object size is the value for red LED type at maximum sensitivity. Note that the corresponding setting distance is different from the rated sensing distance.
5) The allowable cutting range is 700 mm 27.559 in from the end that the amplifier inserted.



# **LIST OF FIBERS**

Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

/pe	Shape of fiber head	Sensing range (mm in)(Note 2, 3)	■ : U-LG = : FAST ■ : LONG = : H-SP ■ : STDF = : S-D	Min. sensing object	Fiber cable length	Bending radius	Model No
		370 14.567 270 10.630 170 6.693 110 4.331	85 3.346 45 1.772 39 1.535	(Note 4)	Free-cut	R25 mm R0.984 in	FD-S80
40.118	¢3 ¢0.118	110 4.331 250 9.843 190 7.480 110 4.331 90 3.543	60 2.362 25 0.984 32 1.260	¢0.02 mm	*	R1 mm R0.039 in	FD-WS8
07 87		85 3.346 66 2.559 37 1.457 32 1.260	25 0.984 10 0.394 11 0.433		2 m 6.562 ft	R2 mm R0.079 in	FD-WSG4
	<b>¢3 ¢</b> 0.118	130 5.118 90 3.543 55 2.165 45 1.772	30 1.181 13 0.512 16 0.630			R4 mm R0.157 in Flexible	FD-P50
φ2.5		140 5.512 90 3.543 60 2.362 45 1.772	35 1.378 16 0.630 16 0.630 10 0.630		2 m 6.562 ft	R25 mm R0.984 in	FD-SNFM
φ1.5		80 3.150 50 1.969 30 1.181 25 0.984	19 0.748 7.5 0.295 9 0.354		1 m 3.281 ft	R4 mm R0.157 in Flexible	FD-P2
ll diamatar			4 0.157 12 0.079 11 0.039		1 m	R10 mm R0.394 in	FD-E12
ltra_cma			17 0.669 8 0.315 7 0.276		3.281 ft	R25 mm R0.984 in	FD-E22
	Small diameter $\phi_1 5 \phi_{0.059}$ $\phi_3 \phi_{0.118}$ Sleeve part cannot be bent	25 0.984	17 0.669 8 0.315 9 0.354			R25 mm R0.984 in	FD-V41
Cida_viaw	$\phi_{3}$ $\phi_{2}$ $\phi_{0,118}$ $\phi_{0,079}$ Sleeve part cannot be bent.		15 0.197 Cannot use Cannot use		2 m 6.562 ft	<mark>R1 mm</mark> R0.039 in	FD-WV42
	<u> </u>		32 1.260 15 0.591 16 0.630			R25 mm R0.984 in	FD-SFM2S
	Glass substrate detection · Mapping	12 to 50 0.4/2 to 1.959 12.5 to 37.5 0.492 to 1.476 15 to 36 0.591 to 1.417 15 to 35 0.591 to 1.477	16 to 29 0.630 to 1.142 Cannot use Cannot use		→ 4 m 13.123 ft	R25 mm R0.984 in	FD-L46
	Glass substrate detection · Alignment	0 to 50 0 to 1.969	0 to 30 0 to 1.181 0 to 15 0 to 0.591 0 to 21 0 to 0.827	(LCD glass)	<mark>≫</mark> 3 m 9.843 ft	R4 mm	FD-L45
	Glass substrate detection · Alignment	0 to 23 0 to 0.906		(LCD glass)	2 m 6.562 ft	R0.157 in	FD-L43
ortive true		0 to 8.2 0 to 0.323 0 to 7 0 to 0.276 0 to 6.5 0 to 0.256 0 to 6 0 to 0.236	0 to 5.7 0 to 0.224 0 to 5 0 to 0.197 0 to 5.2 0 to 0.205	¢0.03 mm	×	R10 mm	FD-L44
Convergent reflective tv	W12×H19×D3 W0.472×H0.748×D0.118	0  to  4 0  to  0.157	0 to 3.8 0 to 0.150 0 to 3 0 to 0.118 10 to 3.5 0 to 0.138	gold wire	2 m 6.562 ft	R0.394 in	FD-L44S
Como	Glass substrate detection	6.5 to 14.5 0.256 to 0.571 (Convergent point 8 0.315 6.5 to 14 0.256 to 0.551 (Convergent point 8 0.315 7 to 14 0.276 to 0.551 (Convergent point 8 0.315 7 to 12 0.276 to 0.472 (Convergent point 8 0.315)	)	$\phi$ 1.9 mm $\phi$ 0.075 in metal pipe (gray)		R1 mm R0.039 in	FD-WL41
	W24×H21×D4	2 to 19 0.079 to 0.748 (Convergent point 8 0.315 2.5 to 18 0.098 to 0.709 (Convergent point 8 0.315 3 to 16 0.118 to 0.630 (Convergent point 8 0.315 3 to 16 0.118 to 0.630 (Convergent point 8 0.315	Cannot use		2 m 6.562 ft	R10 mm	FD-L41
	W6×H18×D14 W0.236×H0.709×D0.551	4 to 12 0.157 to 0.472 (Convergent point 6 0.236	<ul> <li>1 5 to 8.5 0.197 to 0.335 (Convergent point 6 0.236)</li> <li>1 4.8 to 9.5 0.189 to 0.374 (Convergent point 6 0.236)</li> </ul>			R0.394 in	FD-L4
	W7.2×H7.5×D2	<ul> <li>0.5 to 8.5 0.020 to 0.335</li> <li>0.5 to 7.5 0.020 to 0.295</li> <li>1 to 6.5 0.039 to 0.256</li> </ul>	1 to 5 0.039 to 0.197 Cannot use Cannot use	¢0.3 mm ¢0.012 in	<mark>≫</mark> 1 m	R1 mm R0.039 in	FD-WL48

2) The sensing range is specified for white non-glossy paper (FD-S80, FD-WS8: 400 × 400 mm 15.748 × 15.748 in, FD-WSG4, FD-P50, FD-SNFM2, FD-V41, FD-SFM2SV2: 200 × 200 mm 7.874 × 7.874 in, FD-P2, FD-E12, FD-E22, FD-WV42, FD-L4, FD-WL48: 100 × 100 mm 3.937 × 3.937 in, FD-L46, 100 × 10.7 mm 3.937 × 3.937 × 1.0.28 in R edge of LCD glass substrates, FD-L43, FD-L44 and FD-L45: 100 × 100 × 1.0 7 mm 3.937 × 3.937 × 1.0.28 in R edge of LCD glass substrates, FD-L44, FD-L41 in 00 × 100 × 1.0 7 mm 3.937 × 3.937 × 1.0.028 in LCD glass substrates, FD-L44S: silicon wafers polished surface, FD-WL41, FD-L41: 100 × 100 × 1.2 mm 3.937 × 3.937 × 1.0.079 in glass substrates).
3) Please take care that the sensing range of the free-cut type fiber may be reduced by 20% max. depending upon how the fiber is cut.
4) The minimum sensing object size is the value for red LED type at maximum sensitivity. Note that the corresponding setting distance is different from the rated sensing distance. However, with the covergent reflective type, when the sensitivity is at MAX., it is only possible to detect the minimum size of the sensing object at a distance corresponding to the convergent point.

SUNX

# **LIST OF FIBERS**

# Pliable fibers (flexible and sharp bending fibers) are marked with light blue in the table.

		5 / FX-301 (Red LED ive type	0 type) sensing range (Note 1)	<b>FX-305</b> : H-SP, <b>FX-301</b> (- <b>HS</b> ):		DF, LONG, U T, STD, LON	J-LG (no S G (no STE	S-D mode) OF or U-LG mode)
Ту	pe	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2, 3)	■ : U-LG = : FAST = : LONG = : H-SP = : STDF = : S-D = : STD	Min. sensing object (Note 4)	Fiber cable length	Iradiua	Model No.
		Front sensing W10×H7×D2 W0.394×H0276×D0.079	1 to 50 0.039 to 1.969 1.5 to 34 0.059 to 1.339 2 to 24 0.079 to 0.945 3 to 17 0.098 to 0.906	3 to 10 0.118 to 0.394 Cannot use Cannot use	¢0.16 mm ∲0.006 in	*		FD-WZ4
Rectangular	Small	Fiber bending type	1 to 70 0.039 to 2.756 1 to 46 0.039 to 1.811 1 to 32.2 0.039 to 1.268 2.5 to 23 0.098 to 0.906	2.5 to 15 0.098 to 0.591 3 to 7 0.118 to 0.276 3 to 7 0.118 to 0.276	copper wire	1 m 3.281 ft	R1 mm	FD-WZ4HB
Recta	Sn	Front sensing W14×H7×D3.5 W0.551×H0276×D0.138	200 7.874 120 4.724 1 to 84 0.039 to 3.307 1 to 60 0.039 to 2.362	1.5 to 35 0.059 to 1.378 2.5 to 18 0.098 to 0.709 2.5 to 18 0.098 to 0.709	¢0.03 mm ¢0.0012 in	×	R0.039 in	FD-WZ7
		Fiber bending type W3.5 X H14 X D11 W0.138 X H0.551 X D0.433	0.5 to 270 0.002 to 10.630 0.5 to 180 0.002 to 7.087 1 to 126 0.039 to 4.961 1 to 90 0.039 to 3.543	1 to 70 0.039 to 2.756 1 to 35 0.039 to 1.378 1 to 35 0.039 to 1.378	gold wire	2 m 6.562 ft		FD-WZ7HB
	Long sens range	Long sensing range - Rectangular head <b>W5.2</b> × H9.5 × D15 W0.205 × H0.374 × D0.591	20 to 660 0.787 to 25 994 20 to 480 0.787 to 18.898 20 to 300 0.787 to 18.998 20 to 300 0.787 to 11.811 20 to 230 0.787 to 9.055	20 to 170 0.787 to 6.693 25 to 90 0.984 to 3.543 25 to 100 0.984 to 3.937	¢0.3 mm ¢0.012 in copper wire	2 m 6.562 ft	R1 mm R0.039 in	FD-WKZ1
	Wide beam	₩7×H15×D30 W0.276×H0.591×D1.181	230 9.055 200 7.874 150 5.906 150 5.906	100 3.937 45 1.772 50 1.969		2 m 6.562 ft	R25 mm R0.984 in	FD-A15
	Array	Top sensing W5 × H20 × D20 W0.197 × H0.787 × D0.787	290 11.417 220 8.661	78 3.071 35 1.378	¢0.02 mm	<mark>≫</mark> 2 m	R25 mm	FD-AFM2
Special	An	Side sensing	135 5.315 110 4.331	39 1.535		6.562 ft	R0.984 in	FD-AFM2E
	nsing	Contact type				2 m 6.562 ft (Note 5)	Protective tube R40 mm R1.575 in Fiber R15 mm R0.591 in	FD-F8Y
	Liquid level sensing	Mountable on pipe- Standard W25 × H13 × D20 W0.984 × H0.512 × D0.787	Applicable pipe diameter: Outer dia. $\phi$ 6 to $\phi$ 26 mm $\phi$ 0.236 to $\phi$ 1.024 [PVC (vinyl chloride), fluorine resin, polycarbonate, acrylic, glas		(Liquid)	≥~ 2 m	R10 mm	FD-F41
	Liquic	Mountable on pipe · For PFA, wall thickness 1 mm 0.039 in pipe W25 × H13 × D20 W0.984 × H0.512 × D0.787	Applicable pipe diameter: Outer dia. $\phi$ 6 to $\phi$ 26 mm $\phi$ 0.236 to $\phi$ 1.024 [PFA (fluorine resin) or equivalently transparent			6.562 ft	R0.394 in	FD-F4

#### . **/**••• <u>م</u>

Notes: 1) Refer to p.27 for the sensing ranges for the **FX-301-HS** in H-SP mode and for the **FX-301B/G/H**. 2) The sensing range is specified for white non-glossy paper [200 × 200 mm 7.874 × 7.874 in (**FD-WKZ1**, **FD-AFM2**, **FD-AFM2E**: 400 × 400 mm 15.478 × 15.478 in)] as the object.

as the object. 3) Please take care that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut. 4) The minimum sensing object size is the value for red LED type at maximum sensitivity. Note that the corresponding setting distance is different from the rated sensing distance. 5) The allowable cutting range is 1,000 mm 39.370 in from the end that the amplifier inserted.



# **LIST OF FIBERS**

Туре	Shape of fiber head (mm in)	Sensing range (mm in)(Note 2, 3)	U-LG LONG STDF	: FAST : H-SP : S-D	Min. sensing object	length	Bending radius	Model No.	
	350 °C 662 °F • Coaxial		STD : STD		(Note 4)	riee-cul	R25 mm R0.984 in	FD-H35-M2	
	350 °C 662 °F - Sleeve 60 mm 2.362 in 42.8 M6 0.10	300 11.811 270 10.630 150 5.906	100 3 35 1.378 47 1.850	3.937		2 m 6.562 ft	Fiber R25 mm R0.984 in Sleeve R10 mm R0.394 in	FD-H35-M2S	
	200 °C 392 °F · Coaxial M6	140 5.512					R0.394 in R25 mm R0.984 in	FD-H20-M1	
al Heat-resistant	350 °C 662 °F - Sleeve 90 mm 3.543 in ∞ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	190 7.480 160 6.299 80 3.150 80 3.150	57 2.244 20 0.787 26 1.024		¢0.02 mm	1 m 3.281 ft	Fiber R25 mm R0.984 in Sleeve R10 mm R0.394 in	FD-H35-20	
Special Heat-re	200 °C 392 °F · Coaxial	300 11.811 270 10.630 150 5.906 140 5.512	100 3 35 1.378 47 1.850					FD-H20-21	
Spe	2000 X D0.197	0 to 20 0 to 0.787 0 to 15 0 to 0.591 0 to 10 0 to 0.394 0 to 10 0 to 0.394	1 to 8 0.039 to 0.3 Cannot use 2 to 6 0.079 to 0.23	36	_	2 m 6.562 ft	R25 mm	FD-H30-L3	
	¶ × D0.197	0 to 20 0 to 0.787 0 to 15 0 to 0.591 0 to 10 0 to 0.394 0 to 10 0 to 0.394 10 to 10 0 to 0.394	1 to 8 0.039 to 0.3 Cannot use 2 to 6 0.079 to 0.23	36		<mark>≫</mark> 2 m	R0.984 in	FD-H18-L3	
	130 °C 266 °F M6 300 °C 572 °F · Recfangular head	410 16.142 310 12.205 200 7.874 140 5.512 20 to 300 0.787 to 11.8	100 3 55 2.165 47 1.850	00 1.181 to 3.937		6.562 ft		FD-H13-FN	
tant	W9.5 × H5.2 × D15 W0.374 × H0.205 × D0.591	20 to 200 0.787 to 7.874 20 to 150 0.787 to 5.906 25 to 130 0.984 to 5.118	Cannot use Cannot use	00 1.161 (0 3.957	¢0.8 mm	¢0.8 mm	1 m 3.281 ft	R18 mm	FD-H30-KZ1V (Note 5)
n-resist				-7	φ0.031 in		D0 700 in		
2	300°C572°F. Glass substrate detection Convergent reflective type           W1XH5X 027           W0X48X 013°F           Neefer to p.27 for the sem:           The sensing range is spe glass substrate, FD-H300           Please take care that the D The minimum sensing of	0 to 11 0 to 0.433 0 to 8 0 to 0.315 1.5 to 6 0.059 to 0.236 1.5 to 5 0.059 to 0.197 sing ranges for the <b>FX-301-HS</b> in H-SP mo cified for white non-glossy paper [400 × 4 <b>-KZ1V-S, FD-H30-L32V-S</b> : 100 × 100 × t s sensing range of the free-cut type fiber m bject size is the value for red LED type at r	00 mm 15.748 × 15.748 0.7 mm 3.937 × 3.937 > ay be reduced by 20 %	/G/H. 3 in (FD-H30 < t 0.028 in t max. depend	gold wire -L32, FD-H18 ransparent gla ding upon how	ss)] as the the fiber is	object. s cut.	(Note 5)	
otes: 1 2 3 4 5 <b>Iodel</b> Vacut F <b>D-H3</b>	<ul> <li>300 °C 572 °F · Glass substrate detection Convergent reflective type</li> <li>WIX16X 027</li> <li>WIX16X</li></ul>	0 to 11 0 to 0.433 0 to 8 0 to 0.315 1.5 to 6 0.059 to 0.236 1.5 to 5 0.059 to 0.197 sing ranges for the <b>FX-301-HS</b> in H-SP mo cified for white non-glossy paper [400 × 4 - <b>KZ1V-S, FD-H30-L32V-S</b> : 100 × 100 × t sensing range of the free-cut type fiber m	Cannot use Cannot use de and for the <b>FX-301B</b> 00 mm 15.748 × 15.748 0.7 mm 3.937 × 3.937 × ay be reduced by 20 % naximum sensitivity. No <b>/-BR1</b> ) + fiber at atmos <b>dually as replaced</b> (Z1V • Photo-	/G/H. B in (FD-H30 < t 0.028 in t max. depend te that the co spheric side	-L32, FD-H18 ransparent gla ding upon how orresponding s (FT-J8). Plea	<ul> <li>9.843 ft</li> <li>-L31: 50 ×</li> <li>ss)] as the tiber is setting dist.</li> <li>se refer to</li> <li>Fiber at</li> </ul>	50 mm object. s cut. ance is d	1.969 × 1.969 ifferent from n resistant fi oheric side	
Lotes: 1 2 3 4 5 5 10 6 10 7 10 7 10 7 10 7 10 7 10 7 10 7	Convergent reflective type     W1XH5XD27     W1XH5XD2	0 to 11 0 to 0.433 0 to 8 0 to 0.315 1.5 to 6 0.059 to 0.236 1.5 to 5 0.059 to 0.197 sing ranges for the <b>FX-301-HS</b> in H-SP mc colfied for white non-glossy paper [400 × 4 -KZ1V-S, <b>FD-H30-L32V-S</b> : 100 × 100 × 1 sensing range of the free-cut type fiber m oject size is the value for red LED type at the mg vacuum type fiber + photo-terminal ( <b>F</b> ' <b>vacuum-resistant fibers indivi</b> • Mounting bracket for <b>FD-H30-H</b> <b>MS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS-FD-2</b> <b>WS</b>	Cannot use Cannot use de and for the <b>FX-301B</b> 00 mm 15.748 × 15.748 0.7 mm 3.937 × 3.937 × ay be reduced by 20 % naximum sensitivity. No <b>/-BR1</b> ) + fiber at atmos <b>dually as replaced</b> (Z1V • Photo-	/G/H. in (FD-H30 (to.028 in t max. dependent te that the closed the that the closed ment part terminal T (one pa	-L32, FD-H18 ransparent gla ding upon how orresponding s (FT-J8). Plea	<ul> <li>9.843 ft</li> <li>-L31: 50 ×</li> <li>ss)] as the tiber is setting dist.</li> <li>se refer to</li> <li>Fiber at</li> </ul>	50 mm <sup>-</sup> object. s cut. ance is d 'Vacuur	(Note 5) $1.969 \times 1.969$ ifferent from n resistant fi oheric side r set)	
CCCCS F-003 F-13 X-CT1 X	<ul> <li>(a) ************************************</li></ul>	0 to 11 0 to 0.433 0 to 8 0 to 0.315 1.5 to 6 0.059 to 0.236 1.5 to 5 0.059 to 0.197 sing ranges for the <b>FX-301-HS</b> in H-SP mo- ceified for white non-glossy paper [400 × 4 <b>- KZ1V-S, FD-H30-L32V-S</b> : 100 × 100 × t e sensing range of the free-cut type fiber mo- ject size is the value for red LED type at the sensing range of the free-cut type fiber mo- g vacuum type fiber + photo-terminal ( <b>F</b> ' <b>vacuum-resistant fibers indivi</b> • Mounting bracket for <b>FD-H30-H</b> <b>MS-FD-2</b> <b>W</b> <b>th fibers</b> ) lusive mirror) • <b>R</b> length fiber, Orange) Im $\phi 0.087$ in fiber, Clear orange) m $\phi 0.051$ in fiber, Gray) (413 mm $\phi 0.051$ in fiber, Gray) (413 mm $\phi 0.051$ in fiber, Gray)	Cannot use Cannot use de and for the FX-301B 00 mm 15.748 × 15.748 0.7 mm 3.937 × 3.937 × ay be reduced by 20 % naximum sensitivity. No V-BR1) + fiber at atmos dually as replaced X21V • Photo- FV-BI	/G/H. 3 in (FD-H30 max. dependent te that the classification ispheric side ment part terminal R1 (one pa	gold wire -L32, FD-H18 ransparent gla bing upon how orresponding s (FT-J8). Plea is ir set) • FX-CT1 • FX-CT1	<ul> <li>9.843 ft</li> <li>-L31: 50 ×</li> <li>ss)] as the tiber is setting dist.</li> <li>se refer to</li> <li>Fiber at</li> </ul>	50 mm object. s cut. ance is d • Vacuur t atmosp (one pair • FX-C	(Note 5) 1.969 × 1.963 ifferent from n resistant fi oheric side r set) T2	
CCCCS CCCCS CCCCS F-003 F-13 CCCT X-CT X-CT X-CT X-AT X-	<ul> <li>(a) ************************************</li></ul>	0 to 11 0 to 0.433     0 to 8 0 to 0.315     1.5 to 6 0.059 to 0.236     1.5 to 5 0.059 to 0.197     sing ranges for the <b>FX.301-HS</b> in H-SP mo excited for white non-glossy paper [400 × 4 <b>-KZ1V-S, FD-H30-L32V-S:</b> 100 × 100 × t a sensing range of the free-cut type fiber m oject size is the value for red LED type at t a g vacuum type fiber + photo-terminal ( <b>F vacuum-resistant fibers indivi</b> • Mounting bracket for <b>FD-H30-H MS-FD-2 v</b>	Cannot use Cannot use de and for the <b>FX-301B</b> 00 mm 15.748 × 15.748 0.7 mm 3.937 × 3.937 × ay be reduced by 20 % naximum sensitivity. No <b>J-BR1</b> ) + fiber at atmos <b>dually as replacer</b> (Z1V • Photo- <b>FV-BI</b>	/G/H. in (FD-H30 (to.028 in t max. dependent te that the closed the that the closed ment part terminal T (one pa	gold wire -L32, FD-H18 ransparent gla bing upon how orresponding s (FT-J8). Plea is ir set) • FX-CT1 • FX-CT1	<ul> <li>9.843 ft</li> <li>-L31: 50 ×</li> <li>ss)] as the tiber is setting dist.</li> <li>se refer to</li> <li>Fiber at</li> </ul>	50 mm object. s cut. ance is d 'Vacuur t atmosp (one pai	(Note 5) 1.969 × 1.96 ifferent from n resistant f oheric side r set) T2	

SUNX

# LIST OF SENSING RANGE FOR FX-301(P)-HS · FX-301B/G/H

# Sensing range for ultra high-speed type FX-301(P)-HS in H-SP mode (35 µs)(Typical model)

$\backslash$	Fiber model No.	Sensing range (mm in) (Note)		Fiber model No.	Sensing range (mm in) (Note)
е	FT-B8	160 6.299		FD-B8	60 2.362
n type	FT-FM2	120 4.724	type	FD-FM2	35 1.378
Thru-beam	FT-NFM2	40 1.575	Reflective	FD-NFM2	14 0.551
hru-l	FT-E12	2 0.079	Refle	FD-E12	1 0.039
Т	FT-E22	10 0.394		FD-E22	5 0.197

Note: The sensing ranges are in H-SP mode. The sensing ranges in FAST, STD, S-D and LONG modes are the same as for the FX-301. (Refer to p.18~)

# Sensing range for FX-301B/G/H (Typical model)

						Th	ru-beam ty	/pe				
		FT-B8	FT-FM2	FT-NFM2	FT-V10	FT-W8	FT-Z8	FT-P80	FT-A30	FT-A8	FT-E12	FT-E22
	LONG	220 <mark>8.66</mark> 1	150 <mark>5.906</mark>	50 1.969	400 15.748	90 3.543	120 4.724	130 <u>5.118</u>	2,400 94.488	600 23.622	3 0.118	14 0.551
FX-301B	STD	110 4.331	75 <mark>2.95</mark> 3	25 0.984	200 7.874	45 1.772	60 2.362	65 <u>2.55</u> 9	1,200 47.244	300 11.811	2 0.079	7 0.276
	FAST	75 2.953	40 1.575	16 0.630	130 <u>5.118</u>	30 1.181	40 1.575	45 1.772	700 27.559	220 <u>8.66</u> 1	1 0.039	4 0.157
	LONG	110 4.331	70 2.756	24 0.945	200 <b>7.874</b>	56 2.205	60 2.362	70 2.756	1,200 47.244	300 11.811	1 0.039	6 0.236
FX-301G	STD	55 2.165	35 1.378	12 0.472	100 3.937	28 1.102	30 1.181	35 1.378	600 23.622	150 <u>5.906</u>		3 0.118
	FAST	40 1.575	24 0.945	8 0.315	65 2.559	20 0.787	22 0.866	25 0.984	350 13.780	110 4.331		2 0.079
	LONG	100 3.937	50 1.969	16 0.630	150 <u>5.906</u>	42 1.654	46 1.811	56 2.205	800 31.496	220 8.661	4 0.157	10 0.394
FX-301H (Note)	STD	50 1.969	25 <mark>0.98</mark> 4	8 0.315	75 2.953	21 0.827	23 0.906	28 1.102	400 15.748	110 4.331	2 0.079	5 0.197
(INOLE)	FAST	30 1.1 <mark>8</mark> 1	18 0.709	5 0.197	40 1.575	15 0.591	16 0.630	20 0.787	240 9.449	80 3.150	1.5 0.059	3 0.118
Note: Infrared	types are eas	silv affected I	by humidity	so if using th	nem in envira	nments with	high humid	lity or where	the humidity	, fluctuates r	lease conta	ct our office

Note: Infrared types are easily affected by humidity, so if using them in environments with high humidity or where the humidity fluctuates, please contact our office. (mm in)

						R	eflective typ	be				
		FD-B8	FD-FM2	FD-NFM2	FD-W8	FD-P80	FD-AFM2	FD-G4	FD-EG1	FD-E12	FD-E22	FD-G6X
	LONG	80 3.150	46 1.811	16 0.630	23 0.906	40 1.575	40 1.575	22 0.866	6 0.236	2 0.079	6 0.236	22 0.866
FX-301B	STD	40 1.575	23 0.906	8 0.315	11 0.433	20 0.787	20 0.787	11 0.433	3 0.118	1 0.039	3 0.118	11 0.433
	FAST	26 1.024	15 0.591	5 0.197	8 0.315	13 0.512	13 0.512	8 0.315	2 0.079		2 0.079	6 0.236
	LONG	42 1.654	24 0.945	8 0.315	14 0.551	20 0.787	18 0.709	12 0.472	3 0.118	1 0.039	3 0.118	12 0.472
FX-301G	STD	21 0.827	12 0.472	4 0.157	7 0.276	10 0.394	9 0.354	6 0.236	1.5 0.059		1.5 0.059	6 0.236
	FAST	14 0.551	8 0.315	2 0.079	4 0.157	7 0.276	5 0.197	4 0.157	1 0.039		1 0.039	4 0.157
	LONG	26 1.024	20 0.787	6 0.236	11 0.433	18 0.709	12 0.472	7 0.276	10 0.394	1 0.039	6 0.236	18 0.709
FX-301H (Note)	STD	13 0.512	10 0.394	3 0.118	5.5 0.217	9 0.354	6 0.236	3.5 0.138	5 0.197		3 0.118	9 0.354
()	FAST	9 0.354	7 0.276	2 0.079	3 0.118	6 0.236	4 0.157	2 0.079	3 0.118		2 0.079	5 0.197

Note: Infrared types are easily affected by humidity, so if using them in environments with high humidity or where the humidity fluctuates, please contact our office.

# Sensing range when using in combination with FR-WKZ11 reflector (optional)

The sensing ranges are the values for **FX-305** / **FX-301** infrared types.

(mm in)

(mm in)

RF-230	100 to 3,200 3.937 to 125.984 (LONG), 100 to 2,000 3.937 to 78.740 (STD), 100 to 1,600 3.937 to 62.992 (FAST), 100 to 1,000 3.937 to 39.370 (S-D)
RF-220	100 to 2,400 3.937 to 94.488 (LONG), 100 to 1,300 3.937 to 51.181 (STD), 100 to 1,000 3.937 to 39.370 (FAST), 100 to 600 3.937 to 23.622 (S-D)
RF-210	100 to 1,100 3.937 to 43.307 (LONG), 100 to 700 3.937 to 27.559 (STD), 100 to 550 3.937 to 21.654 (FAST), 100 to 300 3.937 to 11.811 (S-D)

Note: The sensing range indicates the allowable setting range for the reflector. The fiber head can detect objects at distances of 100 mm 3.937 in or less. However, note that if there are any white or highly-reflective surfaces near the fiber head, reflected incident light may affect the fiber head. If this occurs, adjust the threshold value of the amplifier before use.



# **FIBER OPTIONS**

# Lens (For thru-beam type fiber)

C	esignation	Model No.		l	Descriptior	1						
				Increases the sensing	Sensing ra	nge for	red LEI	D type (m	nm) [Len	s on bot	h sides	] (Note 3)
				range by 5 times or more.	Fiber	U-LG	LONG		STD	FAST	S-D	H-SP
					FT-B8		3.500 Mat			2.000	1.000	1.000
				Ambient temperature:	FT-FM2			2 3,500 Note2			1,300	1,000
				- 60 to + 350 °C				2 3,500 Note2			1.300	1.000
	Expansion		all and a second s	-76 to $+662$ °F	FT-R80			2 3,500 Note2		1,600	800	750
	lens	FX-LE1			FT-W8			2 3,500 Note 2		2,000	1,000	900
	(Note 1)		2					2 3,500 (Note 2			1,100	1,000
			al a			3,500 (Note 2	3,500 Mate	2) 3,500 (Note 2	3,500 (Note 2)	1,500	900	800
		l '			FT-P81X			2 1,600 (Note 2		1,600 (Note 2)	1,100	950
					FT-H35-M2				2,000	1,500	750	700
					FT-H20W-M1					900	500	400
					FT-H20-M1	1,600 (Note 2	1,600 (Nate	2) <b>1,600</b> (Note 2	1,600 (Note 2)	1,100	900	600
				Tremendously increases the	Sensing ra	nge for	red LEI	D type (n	nm) [Len	s on bo	th sides	] (Note 3)
				sensing range with large	Fiber	U-LG	LONG	STDF	STD	FAST	S-D	H-SP
				diameter lenses.	FT-B8			2 3,500 Mde2		-	-	-
5					FT-FM2			2 3,500 Mile2				
ibe	•			Ambient temperature:				2 3,500 Mde2				
e	Super-		62	- 60 to + 350 °C				2 3.500 Note2				
ď	expansion	FX-LE2		$-76 \text{ to } + 662 ^{\circ}\text{F}$				2 3,500 Note2				
- <del>-</del> -	lens			7010 1002 1				2 3,500 Note2				
an	(Note 1)				FT-P81X			2 1,600 Note2				
pe			1200		FT-H35-M2							3,500 (Note 2)
ż					FT-H20W-M1							1,600 (Note 2)
t					FT-H20-M1	1,600 (Note 2	1,600 (Nda	2 1,600 Note2	1,600 (Nate 2)	1,600 (Note 2)	1,600 (Note 2	1,600 (Note 2)
For thru-beam type fiber					FT-H13-FM2	3,500 (Note 2	3,500 <sub>(Max</sub>	2  <b>3,500</b> (Note 2	3,500 (Nate 2)	3,500 (Ndle 2)	3,500 (Note 2)	3,500 (Note 2)
-				Beam axis is bent by 90 °.			Se	nsing range fo	or red LED ty	pe (mm) [Len	is on both si	des] (Note 3)
							Fil	Mode	LONG	STD	FAST	S-D
				<ul> <li>Ambient temperature:</li> </ul>				T-B8	1.100	530	400	186
				- 60 to + 300 °C				T-FM2	1,200	600	440	210
				- 76 to + 572 °F				T-T80	1,200	600	440	210
	Side-view		a la					T-W8	900	450	330	160
	lens	FX-SV1		1				T-P80	1,200	600	440	210
								T-P60	650	300	200	130
			AT V					T-P81X	1,200	600	440	200
			20 C					T-H35-M2		280	200	90
			e la					T-H20W-M1		140	100	50
							F	T-H20-M1	550	280	200	90
	Expansion		a	Sensing range increases by	Sensing ra	nge for i	red LED	type (mr	n) [Lens	on both	sides] (N	lote 3, 4)
	lens for	FV-LE1		10 times or more.	Fiber	U-LG	LONG	STDF	STD	FAST	S-D	H-SP
	vacuum fiber		1	Ambient temperature:	FT-H30-M1V	1,600	1,200	650	450	300	150	200
	(Note 1)			$-40 \text{ to } + 120 ^{\circ}\text{C} - 40 \text{ to } + 248 ^{\circ}\text{F}$		.,	.,	,				

Notes: 1) Be careful when installing the thru-beam type fiber equipped with the expansion lens, as the beam envelope becomes narrow and alignment is difficult. Especially when installing a fiber with many cores (sharp bending fibers and heat-resistant glass fiber), please be sure to use it only after you have adjusted it sufficiently.
2) The fiber cable length practically limits the sensing range to 3,500 mm 137.795 in long (FT-H20W-M1, FT-P81X and FT-H20-M1: 1,600 mm 62.992 in).
3) The sensing ranges are the values for red LED type amplifier. Please contact our office for details on sensing ranges for other types of amplifiers.
4) The fiber cable length for the FT-H30-M1V is 1 m 3.281 ft. The sensing ranges in U-LG and LONG modes take into account the length of the FT-J8 atmospheric side fiber.

# Lens (For reflective type fiber)

	Designation	Model No.		Description					
	Pinpoint spot lens	FX-MR1		Pinpoint spot of ¢0.5 mm ¢0.020 in. Enable • Distance to focal point: 6 ± 1 mm 0.236 ± • Ambient temperature: − 40 to + 70 °C − √	0.039 in • A	inute objects or sr opplicable fibers: <b>F</b>			
			Screw-in		Sensing rang	Sensing range for red LED type (Note)			
			depth	to $\phi 2 \text{ mm } \phi 0.028$ in to $\phi 0.079$ in according to how much the fiber is screwed in.	Screw-in depth	Distance to focal point	Spot diameter		
	Zoom lens	FX-MR2	Distance to	Applicable fibers: FD-WG4, FD-G4	7 mm	18.5 mm approx.	¢0.7 mm		
			focal point Spot	• Ambient temperature: $-40$ to $+70$ °C $-40$ to $+158$ °F	12 mm 14 mm	27 mm approx. 43 mm approx.	∳1.2 mm ∳2.0 mm		
			→I+ diameter	Accessory: MS-EX-3 (mounting bracket)			,		
fiber				Extremely fine spot of $\phi 0.3 \text{ mm } \phi 0.012 \text{ in}$	Sensing rang	e for red LED	type (Note)		
i iii		FX-MR3			Fiber model No.	Distance to focal point	Spot diameter		
type	Finest spot				FD-EG3	7.5±0.5 mm			
é	lens			FD-EG1, FD-EG2, FD-EG3, FD-G6X, FD-G6	FD-EG2		$\phi$ 0.2 mm approx.		
Ę					FD-EG1		$\phi 0.3$ mm approx.		
je					FD-WG4/G4/G6X/G6	$7.5 \pm 0.5 \text{ mm}$			
For reflective			Distance to	Extremely fine spot of $\phi 0.1 \text{ mm } \phi 0.004 \text{ in}$	Sensing rang	e for red LED	type (Note)		
For			focal point	approx. achieved.	Fiber model No.	Distance to focal point	Spot diameter		
	Finest spot	FX-MR6	Spot diameter	Applicable fibers: FD-WG4, FD-G4,	FD-EG3	7 ± 0.5 mm	<i>ϕ</i> 0.1 mm approx.		
	lens		opor diamotor	FD-EG1, FD-EG2, FD-EG3, FD-G6X, FD-G6	FD-EG2	7 ± 0.5 mm	$\phi 0.15$ mm approx.		
				Ambient temperature:	FD-EG1	7 ± 0.5 mm	<i>ϕ</i> 0.2 mm approx.		
				$-20 \text{ to } +60 ^{\circ}\text{C} -4 \text{ to } +140 ^{\circ}\text{F}$	FD-WG4/G4/G6X/G6	$7\pm0.5$ mm	$\phi$ 0.4 mm approx.		
			Screw-in depth→	FX-MR2 is converted into a side-view type		e for red LED	type (Note)		
	Zoom lens			and can be mounted in a very small space.	Screw-in depth	Distance to focal point	Spot diameter		
	(Side-view)	FX-MH5	Distance	Applicable fibers: FD-WG4, FD-G4	8 mm	13 mm approx.	¢0.5 mm		
	\type /		to focal point	Ambient temperature:	10 mm	15 mm approx.	∲0.8 mm		
				-40  to  +70  °C -40  to  +158  °F	14 mm	30 mm approx.	¢3.0 mm		

Note: The sensing ranges are the values when used in combination with red LED type amplifier. Please contact our office for details on sensing ranges for other types of amplifier.

SUNX

# **FIBER OPTIONS**

# Others


Designation	Model No.				Descriptior	1
	FTP-500 (0.5 m 1.640 ft)	For		FT-B8	FT-P80	
	FTP-1000 (1 m 3.281 ft)	M4 thread			FT-P60 FT-FM2S4	
Protective tube /For thru-beam)	FTP-1500 (1.5 m 4.921 ft)	lineau		FT-H13-FM2		
(type fiber )	FTP-N500 (0.5 m 1.640 ft)	For		FT-T80	FT-P40	
	FTP-N1000 (1 m 3.281 ft)	M3 thread	bers	FT-NFM2 FT-NFM2S		The protective tube, made
	FTP-N1500 (1.5 m 4.921 ft)	lineau	Applicable fibers	FT-NFM2S	64	of non-corrosive stainless steel, protects the inner
	FDP-500 (0.5 m 1.640 ft)	For	olicat	FD-B8	FD-P80	fiber cable from any
	FDP-1000 (1 m 3.281 ft)	M6 thread	Apt	FD-FM2 FD-FM2S	FT-H13-FM2	external forces.
Protective tube /For reflective)	FDP-1500 (1.5 m 4.921 ft)	tineau		FD-FM2S4		
(type fiber)	FDP-N500 (0.5 m 1.640 ft)	For		FD-T80		
	FDP-N1000 (1 m 3.281 ft)	M4 thread		FD-NFM2 FD-NFM2	3	
	FDP-N1500 (1.5 m 4.921 ft)	tirread		FD-NFM2S	54	
Fiber bender	FB-1			nder bends t s. (Note)	the sleeve pa	art of the fiber head at the
Universal sensor	MS-AJ1-F	Horizont	al m	ounting type	Mounting sta	and assembly for fiber
mounting stand	MS-AJ2-F	Vertical	mou	nting type	(For M3, M4	or M6 threaded head fiber)
Fiber cutter	FX-CT2				n be easily cu	it. ne <b>FT-P80</b> or the <b>FD-P80</b> .
	FX-CT1				with fibers oth	
Attachment for fixed-length fiber	FX-AT2	This is t	he a	ttachment for	the fixed leng	gth fiber. (Accessory)
Attachment for $\phi 2.2 \text{ mm}$ $\phi 0.087 \text{ in fiber}$	FX-AT3					n <b>ø0.087 in fiber.</b> <b>T-P80</b> or the <b>FD-P80</b> .)
Attachment for $\phi 1 \text{ mm}$ $\phi 0.039 \text{ in fiber}$	FX-AT4	This is t	he a	ttachment for	the $\phi 1 \text{ mm } q$	
Attachment for $\phi$ 1.3 mm $\phi$ 0.051 in fiber	FX-AT5	This is the attachment for the $\phi$ 1.3 mm $\phi$ 0.051 in fibe (Accessory)				n ¢0.051 in fiber.
Attachment for $\phi 1 \text{ mm}$ $\phi 0.039 \text{ in } / \phi 1.3 \text{ mm}$ $\phi 0.051 \text{ in mixed fiber}$	FX-AT6			attachment fixed fiber. (Ad		nm ¢0.039 in / ¢1.3 mm

Note: Do not bend the sleeve part of any side-view type fiber or ultra-small diameter head type fiber.

# Fiber attachment

It's possible to simultaneously cut two fibers to the same length

Each fiber (with some exceptions) has a newly developed two-in-one fiber attachment (**FX-AT3/AT4/AT5/AT6**) which enables two fibers to be cut simultaneously to the same length with the new fiber cutter (**FX-CT2**). Also, since the fibers can be attached to the amplifier while being fixed in position in the two-in-one fiber attachment, sensitivity changes resulting from variation in the amount of fiber insertion do not occur.






Protective tube • FTP-□ • FDP-□

Fiber bender • FB-1


• FX-CT2



• MS-AJ2-F 360 ° rotation



Angle adjustment: ± 20°



Guide to interchanging fiber length and sleeve length



Custom-ordered products are available with different fiber lengths and sleeve lengths in order to respond quickly to different requirements.

#### **Custom-ordered product (Typical)**

Fiber length can be set up to 30 m 98.425 ft in units of 1 m 3.281 ft ...... FT-B8, FT-AFM2 etc.
 Sleeve length can be set up to 12 cm 4.724 in units of 1 cm 0.394 in ..... FT-FM2S4, FD-NFM2S4 etc.

Please contact us.



# **SPECIFICATIONS**

#### Refer to the 'Sensor general catalog 2003-2004' for fiber specifications.


$\bigwedge$			Standa	ard type		High-speed			
	Туре	Red LED	Blue LED	Green LED	Infrared LED	type	High-function type		
	NPN output	FX-301	FX-301B	FX-301G	FX-301H	FX-301-HS	FX-305		
Item	PNP output	FX-301P	FX-301BP	FX-301GP	FX-301HP	FX-301P-HS	FX-305P		
Supply voltage	-   .			12 to 24	4 V DC ± 10 %	Ripple P-P 10 %	6 or less		
Power consumption	n	Normal operation: 960		nsumption 40 mA or less		Normal operation: 720	reen LED type> mW or less (Current consumption 30 mA or less at 24 V supply voltage) or less (Current consumption 18 mA or less at 24 V supply voltage)		
Output		NPN open-co • Maximum sin • Applied vol • Residual voltage: <pnp output="" ty<br="">PNP open-co • Maximum sou</pnp>	<ul> <li>CNPN output type&gt;</li> <li>NPN open-collector transistor         <ul> <li>Maximum sink current:100 mA (50 mA, if five, or more, amplifiers are connected in cascade)</li> <li>Applied voltage: 30 V DC or less (between output and 0 V)</li> <li>Residual voltage: 1.5 V or less [at 100 mA (at 50 mA, if five, or more, amplifiers are connected in cascade) sink current.         </li> <li>CPNP output type&gt;         PNP open-collector transistor         <ul> <li>Applied voltage: 1.5 V or less [at 100 mA (at 50 mA, if five, or more, amplifiers are connected in cascade) sink current.         </li> <li>CPNP output type&gt;         PNP open-collector transistor 2 output         RNP open-collector transistor 2 output         RNP open-collector transistor 2 output         NPN open-collector transistor 2 output</li></ul></li></ul></li></ul>						
				at 50 mA, if five, or more, a			Residual voltage: 1.5 V or less [at 50 mA (Note 1)]		
Output operati	ion			Selectable	either Light-ON	or Dark-ON, wit	h jog switch		
Short-circuit protection					Incorp	orated			
Response time		250 $\mu$ s or less	$\begin{array}{c} 35 \ \mu \text{s or less [H-SP (Red LED type only)], 150 \ \mu \text{s or less (FAST),} \\ 50 \ \mu \text{s or less [STD / S-D (Red LED type only)],} \\ \text{ms or less (LONG), selectable with jog switch} \end{array} \begin{array}{c} 35 \ \mu \text{s or less (H-SP),} \\ 150 \ \mu \text{s or less (STD / S-D,} \\ 250 \ \mu \text{s or less (STD / S-D),} \\ 250 \ \mu \text{s or less (STD / S-D),} \\ 250 \ \mu \text{s or less (STD), S-D,} $						
Sensitivity setting			2-level teaching / Limit teaching / Manual adjustment / Full-auto teaching / Max. sensitivity teaching / Manual adjustment Window comparator mode:Teaching (1-level / 2-level / 3-level /						
Operation indicator	r			Orang	e LED (lights up	when the output	t is ON)		
Stability indicator		Green LED (ligh	nts up under stab	le light received of	condition or stable	e dark condition)			
MODE indicator		RUN: Green LED, TEACH · ADJ · L/D ON · TIMER · PRO: Yellow LED							
Digital display					4 digit red	LED display			
Fine sensitivity adjust	stment function				Incorp	orated			
Timer function		switchable either effective or ineffective. ONE-SHOT / ON-delay • OFF-delay					Incorporated with variable ON-delay / OFF-delay / ONE-SHOT / ON-delay • OFF-delay / ON-delay • ONE- SHOT timer, switchable either effective or ineffective. (Timer period: Output 1; 0.5 ms, 1 ms to 9399 ms, Output 2; 0.5 ms, 1 ms to 500 ms)		
Light emitting amo function	unt selection			pe only)(Note 2) I, H-SP: 3 level,		Incorporated (Note 2) FAST, STD, LONG: 4 level H-SP, S-D: 2 level	Incorporated (Note 2) FAST, STD, STDF, LONG, U-LG: 4 level H-SP: 3 level		
Automatic interfere prevention function				of fiber heads car mode is 2 fiber			Incorporated [Up to four sets of fiber heads can be mounted close together. (However, U-LG mode is 8 fiber heads, H-SP mode is 2 fiber heads.)] (Note 4)		
Ambient temp	erature						50 °C + 14 to + 122 °F, if 8 to 16 units are connected Storage: $-20$ to $+70$ °C $-4$ to $+158$ °F		
Ambient humi	dity			35	to 85 % RH, Sto	rage: 35 to 85 %	RH		
Ambient illumi	nance	Sı	unlight: 10,000 ℓ	x at the light-ree	ceiving face, Inc	andescent light:	3,000 $\ell x$ at the light-receiving face		
Ambient humi Ambient illumi Voltage withst Insulation resi Vibration resis	andability		1,000 V AC for 0	one min. betwee	n all supply term	inals connected	together and enclosure (Note 5)		
Insulation resi	stance	20 MΩ, (	or more, with 25	0 V DC megger	between all sup	ply terminals co	nnected together and enclosure (Note 5)		
Vibration resis	tance		10 to 150 Hz fre	equency, 0.75 m	m <mark>0.030 in</mark> ampl	itude in X, Y and	Z directions for two hours each		
Shock resistar	nce		98 m/s	<sup>2</sup> acceleration (1	0 G approx.) in	X, Y and Z direc	tions for five times each		
Emitting element (r	modulated)	Red LED	Blue LED	Green LED	Infrared LED	Red LED	Red LED		
Material		Enclosure: Hea	t-resistant ABS, (	Case cover: Polyc	arbonate, MODE	key: Acrylic, Jog	switch: Heat-resistant ABS (FX-301B/G/H: Acrylic)		
Connecting method	d	Connector (Note 6)							
Cable extension		Extension up to total 100 m 328.084 ft (50 m 164.042 ft for 5 to 8 units, 20 m 65.617 ft for 9 to 16 units) is possible with 0.3 mm <sup>2</sup> , or more, cable.							
Weight				Net weigh	it: 20 g approx., (	Gross weight: 25	g approx.		
Notes: 1) 50 mA per	r output. 25 m	A if five, or more,	, amplifiers are d	connected in cas	cade.				

Notes: 1) 50 mA per output. 25 mA if five, or more, amplifiers are connected in cascade. 2) The light emitting amount can be zero (emission halt) in all modes.

2) The spin emining amount can be zero (emission han) in all modes.
3) When the power supply is switched on, the light emission timing is automatically set for interference prevention.
4) When the interference prevention function <sup>(P-2)</sup> is set, the number of mountable fiber heads becomes double. Furthermore, take care that the response time also becomes double.
5) The voltage withstandability and the insulation resistance values given in the above table are for the amplifier only.
6) The cable for amplifier connection is not supplied as an accessory. Make sure to use the optional quick-connection cables given below.

Main cable (3-core) for FX-301(P)(-HS): CN-73-C1 (Cable length 1 m 3.281 ft), CN-73-C2 (Cable length 2 m 6.562 ft), CN-73-C5 (Cable length 5 m 16.404 ft) Sub cable (1-core) for FX-301(P)(-HS): CN-71-C1 (Cable length 1 m 3.281 ft), CN-71-C2 (Cable length 2 m 6.562 ft), CN-71-C5 (Cable length 5 m 16.404 ft) Main cable (2-core) for FX-305(P): CN-74-C1 (Cable length 1 m 3.281 ft), CN-72-C2 (Cable length 2 m 6.562 ft), CN-74-C5 (Cable length 5 m 16.404 ft) Sub cable (2-core) for FX-305(P): CN-72-C1 (Cable length 1 m 3.281 ft), CN-72-C2 (Cable length 2 m 6.562 ft), CN-72-C5 (Cable length 5 m 16.404 ft)

# **I/O CIRCUIT DIAGRAMS**




# PRECAUTIONS FOR PROPER USE



This product is not a safety sensor. Its use is not intended or designed to protect life and prevent body injury or property damage from dangerous parts of machinery. It is a normal object detection sensor.

# **Part description**




Notes: 1) FX-305(P); Output 1 operation indicator (Orange) 2) FX-305(P); Output 2 operation indicator (Orange)

#### Refer to the 'Sensor general catalog 2003-2004' for fiber precautions.

# **Operation procedure**

- · When the power supply is switched on, communication self-check is carried out and normal condition is displayed [MODE indicator / RUN (green) lights up and the digital display shows incident light intensity].
- When MODE key is pressed, the mode changes as per the diagram below.



When jog switch is pressed, the setting is confirmed.

When MODE key is pressed for 2 sec., or more, the sensor returns to the RUN mode. Cancellation is possible by pressing MODE key during setting.

# For FX-305(P)

The FX-305 is equipped with two independent outputs, but the items that can be set in output 1 and output 2 respectively are only the following. The items other than those are common. 1) Threshold value 2) Output operation

Timer operation and Timer period ④ Sensing mode



# PRECAUTIONS FOR PROPER USE

# Teaching

 The threshold values can be set by normal mode (2-level teaching, limit teaching or full-auto teaching) or window comparator mode (1-level / 2-level / 3-level teaching) [FX-305(P) only], when the MODE indicator / TEACH (yellow) lights up.

# In case of 2-level teaching

 This is the method of setting the threshold value by teaching two levels, corresponding to the object present and object absent conditions. Normally, setting is done by this method.

Step	Description	Display
1	Set the fiber within the sensing range. Press the MODE key to light up MODE indicator / TEACH (yellow).	1234
2	For the <b>FX-305(P</b> ), select ' <i>out</i> ' or ' <i>out</i> ' beforehand. Press jog switch in the object present condition. If the teaching is accepted, the read incident light intensity blinks in the digital display. <b>Thru-beam type</b> Reflective type Beam interrupted condition Mark Background	557
3	MODE indicator / TEACH (yellow) blinks. Press the jog switch in the object absent condition. Thru-beam type Reflective type Beam Mark Background	1234
4	If the teaching is accepted, the read incident light intensity blinks in the digital display and the threshold value is set at the mid-value between the incident light intensities in the object present and the object absent conditions. After this, the judgment on the stability of sensing is displayed. In case stable sensing is possible: ' <u>Bood</u> ' is displayed. In case stable sensing is not possible: ' <u>Brod</u> ' blinks.	Sood X8rd
5	The threshold value is displayed.	
6	' · · · · ' blinks in the digital display. (FX-301B/G/H only)	••••
7	The incident light intensity in the digital display and the setting is complete.	1234

Notes: 1) Do not move or bend the fiber cable after the sensitivity setting. Detection may become unstable. 2) In case of using the reflective type fibers, if Jog switch is pressed in the object absent condition at (2) and (3), the sensitivity is set to the maximum.

# In case of full-auto teaching

 Full-auto teaching is used when it is desired to set the threshold value without stopping the assembly line, with the object in the moving condition.

		0						
Step	Description	Display						
1	Set the fiber within the sensing range. Press MODE key to light up MODE indicator / TEACH (yellow).	1234						
2	For the <b>FX-305(P)</b> , select ' <i>loct</i> ' or ' <i>loct</i> ' beforehand. Press the jog switch continuously for 0.5 sec. or more with the object moving on the assembly line. (The incident light intensity is displayed during sampling.)	<u>;;?}Y</u>						
3	$`f_{uto}`$ is displayed on the digital display. Release the jog switch when the object has passed.	Ruto						
4	If the teaching is accepted, the read incident light intensity blinks in the digital display and the threshold value is set at the mid-value between the incident light intensities in							
	<ul> <li>In case stable sensing is not possible: 'good' is displayed.</li> <li>In case stable sensing is not possible: 'good' is displayed.</li> <li>In case stable sensing is not possible: '##r d' blinks.</li> </ul>	X8r d						
5	The threshold value is displayed.	<u> </u>						
6	' · · · · ' blinks in the digital display. (FX-301B/G/H only)	•••						
7	The incident light intensity in the digital display and the setting is complete.	<b>;?</b> }¥						
Notes	Notes: 1) The threshold value's shift amount can be selected in PRO mode.							

 Notes: 1) The threshold value's shift amount can be selected in PRO mode. (Increments of 5% between - 45 and 45% for setting possible. 0% default.)
 2) Do not move or bend the fiber cable after the sensitivity setting. Detection may become unstable.

Downloaded from Elcodis.com electronic components distributor



Refer to the 'Sensor general catalog 2003-2004' for fiber precautions.

# In case of limit teaching

 This is the method of setting the threshold value by teaching only the object absent condition (stable incident light condition). This is used for detection in the presence of a background body or for detection of minute objects.

Step	Description	Display
1	Set the fiber within the sensing range. Press the MODE key to light up MODE indicator / TEACH (yellow).	1234
2	For the <b>FX-305(P</b> ), select ' <i>θu</i> t <i>i</i> ' or ' <i>θu</i> t <i>i</i> ' beforehand. Press the jog switch in the object absent condition. If the teaching is accepted, the read incident light intensity blinks in the digital display. <b>type</b> <b>Reflective type</b> Background body Beam received condition	<u></u>
3	MODE indicator / TEACH (yellow) blinks. Turn jog switch to the ' $+$ ' side or ' $-$ ' side.	123Y
4	If the jog switch is turned to the '+' side, ', ' scrolls (twice)(Note 2) the display from right to left, and the threshold level is shifted to a value approx. 15 % higher (lower sensitivity) + than that set at ②. (Note 1) This is used in case of reflective type fibers. If the jog switch is turned to the '-' side, ', ' 'scrolls (twice) (Note 2) the display from left to right, and the threshold level is shifted to a value approx. 15 % lower (higher sensitivity) than that set at ③. (Note 1) This is used in case of thru-beam ~ type fibers.	J
5	After this, the judgment on whether the setting shift amount can be shifted or not is displayed. • In case shifting is possible: ' good ' blinks. • In case shifting is not possible: ' "", o' blinks.	Sood XRr d
6	The threshold value is displayed.	300
7	' · · · · ' blinks in the digital display. (FX-301B/G/H only)	••••
8	The incident light intensity appears in the digital display and the setting is complete.	<u>;?</u> }Y
Notes	<ul> <li>1) The FX-301B/G/H has no scroll display.</li> <li>2) The approx. 15 % amount of shift is the initial value. The approx. 15 % amount of shift is the initial value. The scale is a scalar of the ROP mode from approx. 5 to 80 %</li> </ul>	

- can be changed in the PRO mode from approx. 5 to 80 % (5 % step). 3) Do not move or bend the fiber cable after the sensitivity setting.
  - Detection may become unstable.


Please refer to the 'Sensor general catalog 2003-2004' or website (http://www.sunx.jp) for setting of threshold value when used in combination with contact type liquid level detection fiber **FD-F8Y**, and for setting of threshold value when used in combination with pipe-mountable liquid level detection fiber **FD-F4**.

# PRECAUTIONS FOR PROPER USE

# Threshold value fine adjustment

Step	Description	Display
1	Press the MODE key to light up MODE indicator / ADJ (yellow).	
2	For the <b>FX-305(P</b> ), select ' <i>lot</i> ' 'o' ' <i>lot</i> ' beforehand. In case the threshold value is to be increased (sensitivity to be reduced), turn the jog switch to the '+' side to increase the threshold value slowly. If the jog switch is turned continuously to the '+' side, the threshold value increases rapidly. In case the threshold value is to be decreased (sensitivity to be increased), turn the jog switch to the '-' side to decrease the threshold value slowly. If the jog switch is turned continuously to the '-' side, the threshold value decreases the '-' side, the threshold value decreases	1235 1235 1235 1235
3	When the jog switch is pressed, the threshold value is confirmed.	

# **Output operation setting**



# **Timer operation setting**

- When the MODE indicator / TIMER (yellow) lights up, you can set the type of timer and whether the timer is to be used or not. For the **FX-301B/G/H**, the type of timer is set in PRO mode.
- Further, an OFF-delay which is useful when the response of the connected device is slow, etc., an ON-delay which is useful to detect only objects taking a long time to travel, and ONE-SHOT, which is useful when the input specifications of the connected device require a signal of a fixed width, are possible with the FX-301□(-HS). [Furthermore, ONdelay • OFF-delay and ON-delay • ONE-SHOT timer are incorporated for FX-305(P).]

# **Cascading amplifiers**

- The FX-301(P), FX-301B/G/H(P) and FX-305(P) cannot use communication for any settings other than the automatic interference prevention function. When using these amplifiers as well, use only the same type of amplifiers all together. However, the FX-301-HS(P) is not equipped with an optical communication function for setting the automatic interference prevention function, so be aware of this when using these amplifiers with other amplifiers.
- If the FX-301(P) updated version unit or the FX-305(P) is mounted with the FX-301(P) previous version unit or the FX-301B/G/H(P) in cascade, place the FX-301(P) updated version units and the FX-305 units to the right side (seen from the connector side) of the previous version units. For a difference between the updated version unit and the previous version unit, refer to 'A difference between the updated version unit and the previous version unit' (P.34).

# PRO mode

• PRO settings can be done when MODE indicator / PRO (yellow) lights up.

# PRO mode table

<						
	Display	Description				
PRO1		Pesponse time change function ' <i>\$P{6'</i> Timer setting function ' <i>4{L}</i> '     Hysteresis function ' <i>#5'</i> Sability function ' <i>5{L}</i> '     Shift function ' <i>5<sup>#</sup>L</i> '     Emitting power selection function ' <i>9<sup>e</sup>LL</i> ' (Note 1)				
PRO2	Prod	<ol> <li>Digital display setting function ' d'5θ'</li> <li>Digital display inversion function ' kura'</li> <li>ECO mode setting function ' kco'</li> </ol>				
PRO3	pro3	<ol> <li>Data bank load setting function ' chl<sup>0</sup>'</li> <li>Data bank save setting function ' ch58'</li> </ol>				
PRO4	Pr 0 4	<ol> <li>Setting condition copy function ' <i>lof</i>?'</li> <li>Remote data bank load setting function ' <i>chl</i>?'</li> <li>Remote data bank save setting function ' <i>chl</i>?'</li> <li>Communication confirmation function ' <i>left</i>?' (Note 2)</li> <li>Back-up function ' <i>b</i> · <i>u</i><sup>ρ</sup>' (Note 3)</li> </ol>				
PRO5	Pros	<ol> <li>Code setting function ' food?'</li> <li>Adjust lock setting function ' food?'</li> <li>Setting reset function ' r St?'</li> <li>Interference prevention function ' loft,' (Note 4)</li> </ol>				
PRO6 (Note 4)	Prob	① Output setting function ' But I', ' But I'				

Notes: 1) FX-301(P) updated version unit, FX-301(P)-HS, FX-305(P) only 2) FX-301B(P)/G(P)/H(P) only

3) FX-301(P) updated version unit, FX-305(P) only
 4) FX-305(P) only

# **Key-lock function**

 If the jog switch and the MODE key are pressed for more than 3 sec. at the same time in RUN mode condition, the key operations are locked, and only the threshold value confirmation function or the adjust function (valid only when the adjust lock function is canceled) is valid.

# Wiring

- When the emission halt of the emitting power switching function is set from 'OFF' to 'ON', the output may be unstable. Do not use the output control for 0.5 sec. after starting emission.
- Make sure that the power supply is off while wiring.
- Verify that the supply voltage variation is within the rating.
- Take care that if a voltage exceeding the rated range is applied, or if an AC
  power supply is directly connected, the sensor may get burnt or damaged.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity
  of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Take care that short-circuit or wrong wiring of the load may burn or damage the sensor.
- Do not run the wires together with high-voltage lines or power lines or put
  them in the same raceway. This can cause malfunction due to induction.
- Ensure that an isolation transformer is utilized for the DC power supply. If an auto transformer is utilized, the main amplifier or power supply may be damaged.
- Make sure to use the optional quick-connection cable for the connection of the amplifier [FX-301(P)(-HS) / FX-305(P)]. Extension up to total 100 m 328.084 ft (50 m 164.042 ft for 5 to 8 units, 20 m 65.617 ft for 9 to 16 units,) is possible with 0.3 mm<sup>2</sup>, or more, cable. However, in order to reduce noise, make the wiring as short as possible.

# Others

- Do not use during the initial transient time (0.5 sec. approx.) after the power supply is switched on.
- Take care that the sensor is not directly exposed to fluorescent light from a rapid-starter lamp or a high frequency lighting device, as it may affect the sensing performance.
- This sensor is suitable for indoor use only.
- · Avoid dust, dirt, and steam.

Take care that the product does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.

- This sensor cannot be used in an environment containing inflammable or explosive gasses.
- Never disassemble or modify the sensor.



# **PRECAUTIONS FOR PROPER USE**

# Refer to the 'Sensor general catalog 2003-2004' for fiber precautions.


# Function table for FX-300 series

	Previous models			New models			
	FX-301(P) (Previous version unit)	FX-302(P)	FX-303(P)	FX-301(P) (Updated version unit)	FX-301(P)-HS	FX-305(P)	
Four-chemical emitting element + APC circuit	×	×	×	0	0	0	
Four-chemical emitting element only	O (Note 1)	0	0	-	—	—	
Light emitting amount selection function	×	×	×	0	0	0	
Reduced intensity mode (S-D)	O (Note 1)	0	×	0	0	_	
9,999 digit display	×	×	×	×	×	0	
Response time (Max. speed)	150 µs	300 µs	90 µs	65 µs	35 µs	65 µs	
Interference prevention function (Effective no. of units)	Incorporated (4)	Incorporated (8)	Not incorporated (0)	Incorporated (4)	Not incorporated (0)	Incorporated (16)	
Independent 2 outputs	×	×	×	×	×	0	
Alarm output function	×	×	×	×	×	0	
Error output function	×	×	×	×	×	0	
Differential sensing	X	×	×	×	×	0	
Window comparator mode	×	0	×	×	×	0	
Peripheral units that can be combined	1						
FX-CH(-P)	Ó	Ó	×	×	×	×	
FX-CH2(-P)	X	×	×	0	×	0	
SC-GU1-485	X	×	×	0	×	0	

Note: Except FX-301B/G/H.

# A difference between the updated version unit and the previous version unit for FX-301 (Red LED type)

# Changes in appearance



Checking minor changes between previous and new models can be done by checking whether the printing is on both sides or only one side.

# Upgraded functions

#### 1. Response times added

An ultra high-speed mode (H-SP) has been added to the existing 4 response time modes [high-speed (FAST), reduced intensity (S-D), standard (STD) and long range (LONG)]. This is changed using 'Prof' in '5PEd'.



#### 2. Extension of timer period

The setting range for the timer period was previously 500 ms, but this has been extended to a new range of 9999 ms.

# 3. Light emitting amount selection function

The light emitting amount can be changed to one of 4 levels (5 levels when emission halt is included).

# 4. Backup, copy lock and key lock functions added

- Backup: This selects whether or not threshold values set by teaching are written to (stored in) an EEPROM.
- Copy lock: This selects whether copy function and data bank function communication are possible or not.
- Key lock: This disables input using switches to prevent accidental changing of settings.

#### Changes in operation

#### 1. Timer selection method

Previous version unit: Timer type was changed using PRO1 mode. The 'TIMER' setting in NAVI mode could only be turned on or off.

After change: The type of timer can be changed using the 'TIMER' function in NAVI mode.

# 2. Checking threshold value in RUN mode

The threshold values can be checked by turning the jog switch.

#### Display changes

After change

# 1. Checking blinking of sensitivity surplus

The stable surplus display method after teaching has been changed.

Previous version unit: Sensitivity surplus is indicated by the number

of blinks of the stability indicator.

#### 2. Initial direct code value changed

The factory default settings for the direct codes have been changed.

Previous version unit 0000 - After change 0004

\* The default setting for the timer period is 10 ms, and the direct code for 10 ms is '4', so this has been changed.

#### Internal circuit changes


#### 1. Addition of an APC circuit

A four-chemical emitting element which provides stable sensing over long periods has been added, as well as an APC (Auto Power Control) circuit that improves stability during short periods.

#### Points to note when combining sensor types

When using the newer sensors together with previous version units (including the **FX-301B/G/H**), note the following.

- Communication is possible when the previous version units and the updated version units are used in an arrangement such as that shown in Figure A below.
- If the previous version units and the updated version units are used in an arrangement such as that shown in Figure B below, the interference prevention function and the PRO4 function cannot be used.
- In order to use the interference prevention function and the PRO4 function when using previous version units and the updated version units together, it is recommended that you use an arrangement such as that shown in Figure C below.




Updated

version unit

# **DIMENSIONS (Unit: mm in)**

Refer to the 'Sensor general catalog 2003-2004' for fiber dimensions. The CAD data in the dimensions can be downloaded from the website: http://www.sunx.jp/



# Introducing digital laser sensor LS series

# Making high precision laser sensing more intuitive and easier to use

- Minute objects can be sensed even at removed distances.
- 3 types of laser sensor head available.
- Side-by-side placement together with fiber sensors is also possible.

<IC pin check>

<Sensing remaining sheet roll amounts>

For further details, please refer to the SUNX home page (http://www.sunx.co. jp/) or contact our office.

Downloaded from Elcodis.com electronic components distributor




# **External Input Unit for Digital Sensor / FX-CH2**



# Support for stable sensing and smooth setup changes!

Teaching and data bank switching for up to a maximum of 16 digital fiber sensors (FX-301 and FX-305) can be carried out all at once using an external device such as a PLC, touch screen or switch.



# Applications involving smooth setup operations

# Setup changes (external automatic teaching / data bank switching)

Digital fiber settings can be changed using input from a touch screen or switch, so that production line setup changes can be carried out more easily.

# External teaching

Full-auto teaching is recommended for teaching when the sensing object is changed without stopping the line.

# Data bank switching

Settings such as output operations (L-ON / D-ON) and timer operations can be recorded in the digital fiber sensor's data bank and switching can be carried out externally. \* Up to 3 files can be stored.

# **FX-CH2** function list

# **Teaching input**

The following types of external teaching can be carried out.

- Full-auto teaching
  Limit teaching '-'
  Limit teaching '+'
  2-level teaching

# Key lock setting input

The key lock function that prevents incorrect operations by operators can be set on and off.


# Data bank switching input

Switching between 3 channels of data banks and loading and saving of all channels at once can be carried out.

# Product lineup

Connector for input device CN-EP1 [1 pc. included with FX-CH2(-P)]

 Input signal The types of input operations are determined by S1 and S2, and the input timing is determined by S3.





Quick-connection cable CN-73-C (Optional)

MODE

0٧

Mode selection


The MODE wire can be switched between high and low to select the input mode from either 'external teaching and key lock' or 'data bank switching'

# Explanation of limit teaching


# • Limit teaching '-'

Limit teaching '-' shifts the threshold value setting to make it less than the incident light intensity during teaching.

When limit teaching is not used If the incident light intensity changes with respect to the initial threshold setting value because of reasons such as beam axis slippage, sensing can become unstable and incorrect operations can occur.



(When limit teaching ' — ' is used) The threshold value is reset each time before the sensing object arrives, (limit teaching '-'). As a result, sensing is not affected by changes in incident light intensity.




object is present


# Limit teaching ' + '

Limit teaching '+' is the opposite of limit teaching '-', so that the threshold value setting is shifted toward a higher setting to make it more than the incident light intensity during teaching.

When limit teaching is not used) If dust or other particles cause changes in the incident light intensity with respect to the initial threshold setting value, sensing can become unstable and incorrect operations can occur.



When limit teaching ' + ' is used The threshold value is reset each time before the sensing object arrives, (limit teaching '+ result, sensing is not affected by changes in incident light intensity.



% When limit teaching is used, use the SHIFT function in PRO mode of the amplifier to set the shift amount beforehand.



# **ORDER GUIDE**

Design	Model No.	
Endowed in a district of the	NPN input type	FX-CH2
External input unit	PNP input type	FX-CH2-P
Connector for input device (1 pc. included as standard	CN-EP1 5 pcs. per set	
	Length: 1 m 3.281 ft	CN-73-C1
Quick-connection cable (Main cable)	Length: 2 m 6.562 ft	CN-73-C2
(main cable)	Length: 5 m 16.404 ft	CN-73-C5
Endalate	MS-DIN-E	
End plate	2 pcs. per set	

# **SPECIFICATIONS**

~				
Туре	NPN input type	PNP input type		
Item Model No.	FX-CH2	FX-CH2-P		
Applicable sensor	FX-301(P)(Note	e 1), <b>FX-305</b> ( <b>P</b> )		
Supply voltage	12 to 24 V DC $\pm$ 10 %	Ripple P-P 10 % or less		
Power consumption	600 mW or less (when	all indicators light up)		
Input	Low: 0 to + 2 V DC Source current 0.5 mA Input impedance 10 kΩ approx. High: +5 V to + V DC, or open	Input impedance 10 kΩ approx.		
Power indicator	Green LED (Lights up when the power is ON)			
Transmission operation indicator	Green LED (Lights up when loaded, and 2-level / Limit teaching, blinks→lights up when saved, and Full-auto teaching)			
Ambient temperature	connected in cascade: - 10 to 8 to 16 sensors are connected	$\begin{array}{c} 131 \ {}^\circ\mathrm{F} \ (\mathrm{if} \ 4 \ \mathrm{to} \ 7 \ \mathrm{sensors} \ \mathrm{are} \\ \mathrm{o} \ +50 \ {}^\circ\mathrm{C} \ \ +14 \ \mathrm{to} \ +122 \ {}^\circ\mathrm{F}, \ \mathrm{if} \\ \mathrm{in} \ \mathrm{cascade:} \ \ -10 \ \mathrm{to} \ \ +45 \ {}^\circ\mathrm{C} \\ \mathrm{ondensation} \ \mathrm{or} \ \mathrm{cing} \ \mathrm{allowed}), \\ \mathrm{d} \ \mathrm{to} \ \ +158 \ {}^\circ\mathrm{F} \end{array}$		
Material	Enclosure: Heat-resistant ABS			
Cable extension	Extension up to total 10 m 32.808 ft is possible with 0.3 mm <sup>2</sup> , or more, cable.			
Weight	Net weight: 20 g approx., Gross weight: 40 g approx.			
Accessory	CN-EP1 (Connector for input device)(Note 2): 1 pc.			


Notes: 1) Only updated version of FX-301(P) can be used. Do not use the previous version of FX-301(P). The updated version of FX-301(P) have 'NAVI' printed on one side.

(See the right figure.)



2) The applicable wire is 0.08 mm<sup>2</sup> (AWG 28) to 0.5 mm<sup>2</sup> (AWG 20) and the wire sheath diameter should be  $\phi 1.5 \text{ mm } \phi 0.059 \text{ in or less.}$ 

# **I/O CIRCUIT DIAGRAMS**



# **OPERATION TIMING CHART**

# When MODE is set to High (Low for FX-CH2-P) or open

	Data bank load				Da	ta bank sa	ave	
	1ch	2ch	3ch		1ch	2ch	3ch	1
S1	t1		t1	-High Low	t1		t1	-High - Low
S2		t1	t1	-High Low		t1	t1	High Low
S3	→ <u>t2</u> ←	→t2	→t2 ←	- High - Low	t3	t3	t3	-High Low
t1 :	t1 : t1>t2, t1>t3 t2 : 20 ms to less than 2 sec. t3 : 2 sec. or more							

# When MODE is set to Low (High for FX-CH2-P)

	2-level / Full-	auto teaching	Limit te			Key	lock		
	2-level	Full-auto	'+'	· _ ·	1	_	Cancellation	Setting	
S1	t1	t1		t1	-High - Low	S1			-н
S2			t1	₹ <mark>t1</mark>	High Low	S2			Η L
S3	→ <u>t</u> 2	→ <u>t3</u> ←	→ <u>t2</u>	→t2 <b>-</b>	-High -Low	S3	→ <u>t1</u> ←	t2	-н
t1:t1>t2;t1>t3 t2:20 ms to less than 2 sec. (This is the timing period for 1 level. 2 levels are required.)							20 ms to les 2 sec. or mo		c.

Чig Low Hig t2


lig

Lov

t2:20 mt loss than 2 sec. (This is the timing period for 1 level. 2 levels are required.) t3:0.5 sec. or more (Sampling starts after 0.5 sec.)

 Notes: 1) The above diagrams show the FX-CH2 (NPN input type).
 For the FX-CH2-P (PNP input type), High and Low are reversed.
 2) After each operation has been confirmed, the fiber sensor cannot be reset for a period of approximately 50 ms.

# DIMENSIONS (Unit: mm in)



ver supply side

to 24 V DC+

V (Blue)

M(+)

-ò-

Connector pin No. for input device side

-+ Users' circuit

MODE (Blac




# Upper Communication Unit for Digital Sensors / SC-GU1-485



# We now offer remote maintenance for sensors! Also reduces the work required to the system to start running!


Centralized control and setting of scattered digital sensors (FX-301/305) is possible using a PLC or personal computer





# Control and settings can be carried out remotely


Setting and checking incident light intensity for digital sensors (**FX-301/305**) that are scattered inside and outside equipment can be carried out remotely for all sensors by using the **SC-GU1-485**, which greatly improves ease of operations such as monitoring equipment that is running and also equipment starting and maintenance.



Note: Used when the output signal is sent via a SC-GU1-485 to the PLC. If the output signal is sent directly to the PLC, a quick-connection cable (CN-72-C□, CN-71-C□) should be used.

# Less wiring and installation work

Up to a maximum of 16 sensors can be connected side by side. Power can be supplied to all of them at once, so that less wiring and installation work is required. Wire-saving connectors also makes it possible to send output signals to the PLC in a single batch.




# Communication speed 57.6 kbps

High-speed communication at a maximum speed of 57.6 kbps allows the operator to instantly check information such as the incident light intensity and output statuses of the digital sensors.


# High general applicability so that any type of PLC can be used

RS-485 communication provides a high level of general compatibility so that any type of PLC can be used. Integration with existing systems is possible without the need to change PLCs.



RS-485 communication

Series connection of a maximum of 31 nodes is possible A maximum of 31 nodes can be connected in series. This is ideal for flexible handling when the sensors are to be installed in scattered locations or if more sensors are added.





# **SPECIFICATIONS**

Tree	Main unit			
Туре	Main unit			
Item Model No.	SC-GU1-485			
Applicable sensor	FX-301(P)(Note), FX-305(P)			
Connectable units	Max. 16 units of sensor per SC-GU1-485			
Connectable nodes	Max. 31 nodes			
Supply voltage	24 V DC $\pm$ 10 % Ripple P-P10 % or less			
Current consumption	45 mA or less (10 mA or less for SC-GU1-EU)			
Communication method	2 wire half duplex method			
Communication speed	57,600 bps / 38,400 bps / 19,200 bps / 9,600 bps Selectable by DIP switch			
Synchronization method	Asynchronous communication method			
Electrical characteristic	Conforming to EIA RS-485			
Total extension length	Communication cable: 100 m 328.084 ft or less [SC-GU1-485 (termination) to PLC], Power supply cable: Less than 10 m 32.808 ft			
Ambient temperature	$-10$ to $+55\ ^\circ\mathrm{C}$ $+14$ to $+131\ ^\circ\mathrm{F}$ (If 4 to 7 sensors are connected in cascade: $-10$ to $+50\ ^\circ\mathrm{C}$ $+14$ to $+122\ ^\circ\mathrm{F}$ , if 8 to 16 sensors are connected in cascade: $-10$ to $+45\ ^\circ\mathrm{C}$ $+14$ to $+113\ ^\circ\mathrm{F}$ )(No dew condensation or icing allowed), Storage: $-20$ to $+70\ ^\circ\mathrm{C}$ $-4$ to $+158\ ^\circ\mathrm{F}$			
Material	Enclosure: Heat-resistant ABS			
Weight	35 g approx. (10 g approx. for SC-GU1-EU)			
Accessories	SC-GU1-EU (End unit): 1 pc. CN-73-C2 [Quick-connection cable (cable length 2 m 6.562 ft)]: 1 pc. SC-GU1-CC02 [Link cable (cable length 0.2 m 0.656 ft)]: 1 pc.			


Note: Applicable units are for the FX-301(P) after version update. Do not use the previous version of FX-301(P).

NAVI

ĘΞ

The updated version of **FX-301(P)** has the 'NAVI' printed only on single side. (See the right figure.)

# **DIMENSIONS (Unit: mm in)**



All information is subject to change without prior notice.

# SUNX Sensing the Future

http://www.sunx.jp/

SUNX Limited 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan Phone: +81-(0)568-33-7211 FAX: +81-(0)568-33-2631

Overseas Sales Dept. Phone: +81-(0)568-33-7861 FAX: +81-(0)568-33-8591

# **OPERATION VERIFICATION PROGRAM DOWNLOAD SERVICE**

The SUNX website download data service lets you download operation verification programs to a personal computer. (http://www.sunx.co.jp/)

#### Monitoring example



Free hard disk space: 10 MB or more Serial port: RS-232C compatible

Memory: 64 MB or more

Operating environment OS: Windows 98 Second Edition

# Details that can be checked:

Sensor threshold values, output statuses, configuration settings, teaching and timer period setting changes, etc.

(standard English language installation only) or later CPU: Pentium II 400 MHz processor or higher (Pentium III 450 MHz or higher recommended)

(128 MB or more recommended)

Notes: 1) Note the following when using this software.

The software is supplied as freeware. Copyright is retained by SUNX Limited. You must agree to the following conditions before using the software.

#### Conditions of use

- SUNX does not guarantee the correct operation of this software. SUNX takes no responsibility for any direct or indirect losses, damage, loss of profit or any other problems arising as a result of using or operating this software.
- 2) When connecting the SC-GU1-485 to a personal computer, you will need obtain a interface converter (RS-232C RS-485 converter) and cable to connect between the computer and the interface converter.

# OPTION

CN-701 (Wire-saving connector) Note: Used when the output signal is sent via a SC-GU1-485 to the PLC.



