

<p>Fig. 1</p>	<ul style="list-style-type: none"> • Male jumpers are available with or without insulator and have .022" diameter pins with .1", .2" or .3" center spacing. • Female color coded shunts are offered in closed, and open insulators for longer pins. 																									
<p>Ordering Information</p>																										
<p>Fig. 2</p>	<table border="1"> <thead> <tr> <th rowspan="3" style="text-align: center;">Fig. 1</th> <th colspan="2" style="text-align: center;">Male Jumper .100" Spacing</th> </tr> <tr> <th colspan="2" style="text-align: center;">Platings</th> </tr> <tr> <th style="text-align: center;">Color / Style</th> <th style="text-align: center;">10μ" Au</th> <th style="text-align: center;">200μ" Sn/Pb</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Black</td> <td style="text-align: center;">999-11-210-10-000</td> <td style="text-align: center;">999-11-210-90-000</td> </tr> <tr> <td style="text-align: center;">Red</td> <td style="text-align: center;">999-11-210-11-000</td> <td style="text-align: center;">999-11-210-91-000</td> </tr> <tr> <td style="text-align: center;">Not Insulated</td> <td style="text-align: center;">999-11-110-10-000</td> <td style="text-align: center;">999-11-110-90-000</td> </tr> </tbody> </table>		Fig. 1	Male Jumper .100" Spacing		Platings		Color / Style	10μ" Au	200μ" Sn/Pb	Black	999-11-210-10-000	999-11-210-90-000	Red	999-11-210-11-000	999-11-210-91-000	Not Insulated	999-11-110-10-000	999-11-110-90-000							
Fig. 1	Male Jumper .100" Spacing																									
	Platings																									
	Color / Style	10μ" Au	200μ" Sn/Pb																							
Black	999-11-210-10-000	999-11-210-90-000																								
Red	999-11-210-11-000	999-11-210-91-000																								
Not Insulated	999-11-110-10-000	999-11-110-90-000																								
<p>Fig. 2</p>	<table border="1"> <thead> <tr> <th rowspan="3" style="text-align: center;">Fig. 2</th> <th colspan="2" style="text-align: center;">Male Jumper .200" Spacing</th> </tr> <tr> <th colspan="2" style="text-align: center;">Platings</th> </tr> <tr> <th style="text-align: center;">Color / Style</th> <th style="text-align: center;">10μ" Au</th> <th style="text-align: center;">200μ" Sn/Pb</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Black</td> <td style="text-align: center;">999-11-220-10-000</td> <td style="text-align: center;">999-11-220-90-000</td> </tr> <tr> <td style="text-align: center;">Red</td> <td style="text-align: center;">999-11-220-11-000</td> <td style="text-align: center;">999-11-220-91-000</td> </tr> <tr> <td style="text-align: center;">Not Insulated</td> <td style="text-align: center;">999-11-112-10-000</td> <td style="text-align: center;">999-11-112-90-000</td> </tr> </tbody> </table>		Fig. 2	Male Jumper .200" Spacing		Platings		Color / Style	10μ" Au	200μ" Sn/Pb	Black	999-11-220-10-000	999-11-220-90-000	Red	999-11-220-11-000	999-11-220-91-000	Not Insulated	999-11-112-10-000	999-11-112-90-000							
Fig. 2	Male Jumper .200" Spacing																									
	Platings																									
	Color / Style	10μ" Au	200μ" Sn/Pb																							
Black	999-11-220-10-000	999-11-220-90-000																								
Red	999-11-220-11-000	999-11-220-91-000																								
Not Insulated	999-11-112-10-000	999-11-112-90-000																								
<p>Fig. 3</p>	<table border="1"> <thead> <tr> <th rowspan="3" style="text-align: center;">Fig. 3</th> <th colspan="2" style="text-align: center;">Male Jumper .300" Spacing</th> </tr> <tr> <th colspan="2" style="text-align: center;">Platings</th> </tr> <tr> <th style="text-align: center;">Color / Style</th> <th style="text-align: center;">10μ" Au</th> <th style="text-align: center;">200μ" Sn/Pb</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Black</td> <td style="text-align: center;">999-11-230-10-000</td> <td style="text-align: center;">999-11-230-90-000</td> </tr> <tr> <td style="text-align: center;">Red</td> <td style="text-align: center;">999-11-230-11-000</td> <td style="text-align: center;">999-11-230-91-000</td> </tr> <tr> <td style="text-align: center;">Not Insulated</td> <td style="text-align: center;">999-11-113-10-000</td> <td style="text-align: center;">999-11-113-90-000</td> </tr> </tbody> </table>		Fig. 3	Male Jumper .300" Spacing		Platings		Color / Style	10μ" Au	200μ" Sn/Pb	Black	999-11-230-10-000	999-11-230-90-000	Red	999-11-230-11-000	999-11-230-91-000	Not Insulated	999-11-113-10-000	999-11-113-90-000							
Fig. 3	Male Jumper .300" Spacing																									
	Platings																									
	Color / Style	10μ" Au	200μ" Sn/Pb																							
Black	999-11-230-10-000	999-11-230-90-000																								
Red	999-11-230-11-000	999-11-230-91-000																								
Not Insulated	999-11-113-10-000	999-11-113-90-000																								
<p>Fig. 4 Fig. 5</p>	<table border="1"> <thead> <tr> <th colspan="3" style="text-align: center;">SHUNTS</th> </tr> <tr> <th colspan="3" style="text-align: center;">For .025" Square Headers</th> </tr> <tr> <th style="text-align: center;">Color</th> <th style="text-align: center;">Closed Insulator</th> <th style="text-align: center;">Open Insulator</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Black</td> <td style="text-align: center;">999-XX-210-00-000</td> <td style="text-align: center;">999-XX-310-00-000</td> </tr> <tr> <td style="text-align: center;">Red</td> <td style="text-align: center;">999-XX-210-02-000</td> <td style="text-align: center;">999-XX-310-02-000</td> </tr> <tr> <td style="text-align: center;">Blue</td> <td style="text-align: center;">999-XX-210-06-000</td> <td style="text-align: center;">999-XX-310-06-000</td> </tr> <tr> <td></td> <td style="text-align: center;">Fig. 4</td> <td style="text-align: center;">Fig. 5</td> </tr> <tr> <td colspan="3" style="text-align: center;"> <p>Specify Plating Code XX= 19 = 10μ" Selective Gold</p> </td> </tr> </tbody> </table>		SHUNTS			For .025" Square Headers			Color	Closed Insulator	Open Insulator	Black	999-XX-210-00-000	999-XX-310-00-000	Red	999-XX-210-02-000	999-XX-310-02-000	Blue	999-XX-210-06-000	999-XX-310-06-000		Fig. 4	Fig. 5	<p>Specify Plating Code XX= 19 = 10μ" Selective Gold</p>		
SHUNTS																										
For .025" Square Headers																										
Color	Closed Insulator	Open Insulator																								
Black	999-XX-210-00-000	999-XX-310-00-000																								
Red	999-XX-210-02-000	999-XX-310-02-000																								
Blue	999-XX-210-06-000	999-XX-310-06-000																								
	Fig. 4	Fig. 5																								
<p>Specify Plating Code XX= 19 = 10μ" Selective Gold</p>																										