

Low Noise, High Voltage EL Lamp Driver IC Demoboard

General Description


The Supertex HV857DB1 demoboard contains all necessary circuitry to demonstrate the features of the HV857 EL lamp driver.

Simply connect it to a power supply and a lamp. For additional assistance in designing EL driver circuits, please refer to application notes **AN-H33 (effect of external components on performance of Supertex EL drivers)** and **AN-H43 (EL lamp driver circuits to reduce audible noise)**.


Specifications

Parameter	Value
Input voltage:	1.8 to 5.0V
Typical supply current:	26mA
Lamp size:	2.6in ²
Lamp frequency:	206Hz
Converter frequency:	80kHz

Board Layout and Connection Diagram



Actual Dimensions: 12mm x 12mm



Connections:

EN - Enable Input

Enables/Disables the lamp driver. A logic high (connect to V_{DD}) enables the driver, and a logic low (connect to GND) disables the driver. This input can be connected to a mechanical switch or to a logic circuit output that has a source impedance of less than 20k Ω .

V_{DD} - IC Supply

Supplies the HV857 EL driver IC. The supplied circuit is optimized for 3.0V operation. The operating range can be from 1.8 to 5.0V. Connect to positive terminal of a power supply.

Note:

Make sure all the above connections are made before powering up the supply voltages.

V_{IN} - Inductor Supply

Supplies the high voltage power converter. Connect to positive terminal of a power supply.

GND - Circuit Ground

Connect to V_{DD} and V_{IN} negative terminals. Supply bypass capacitor for both V_{DD} and V_{IN} are provided on the demo board. External supply bypass capacitors are not required.

V_A and V_B - Lamp Connections

Connect to an EL lamp. Polarity is irrelevant.

