



Intel® RAID Controller SRCU41L

Tested Hardware and Operating System List

Revision 3.0

June, 2007

Enterprise Platforms and Services Division – Marketing

Revision History

Date	Revision Number	Modifications
06/30/05	1.0	Initial Release
03/25/06	1.1	Update with latest Firmware and Test information
09/20/06	2.0	Update with latest Firmware and Test information
12/20/06	2.1	Update tested hard drive list
06/21/07	3.0	Update with latest Firmware and Test information

Disclaimers

THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE.

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel retains the right to make changes to its test specifications at any time, without notice.

The hardware vendor remains solely responsible for the design, sale and functionality of its product, including any liability arising from product infringement or product warranty.

Copyright © Intel Corporation 2007. All rights reserved.

Intel, the Intel logo, and EtherExpress are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

*Other names or brands may be claimed as the property of others.

Table of Contents

1. Introduction	5
1.1 Test Overview	5
1.1.1 Basic Compatibility Testing	5
1.1.2 Adapter / Peripheral Compatibility and Stress Testing	6
1.2 Pass/Fail Test Criteria	7
2. Intel® RAID Controller SRCU41L Firmware Configurations.....	8
3. Operating Systems.....	9
3.1 Operating System Certifications	11
4. Intel® Server Boards.....	12
5. Enclosures, PCI Adapters, and Peripherals.....	15
5.1 External Storage	15
5.2 Internal Storage	16
5.3 CD-ROM Drives	16
5.4 Tape Drives	16
5.5 Hard Disk Controllers.....	17
5.6 SCSI RAID Controllers	17
5.7 Network Interface Controllers	18
6. Hard Disk Drives.....	19
6.1 Hard Disk Drives.....	19

This page intentionally left blank

1. Introduction

This document is intended to provide users of the Intel® RAID Controller SRCU41L with a guide to the operating systems, server boards, chassis, disk drives, and other peripherals tested by Intel for use with this RAID controller.

This document will be updated as additional testing is performed, or until the RAID Controller SRCU41L is no longer in production. Each release of the document will include the information from previous releases. The latest version of this document is posted on the Internet.

Intel will only support this RAID controller when used in a system configured with the server boards listed, and configured with the versions of RAID firmware, system BIOS / firmware, and operating system versions that were successfully tested. Thorough testing has been performed of the RAID Controller SRCU41L with the Intel® server boards, with Intel drive enclosures, and with the third-party devices listed in this document. It is not practical to test the RAID Controller SRCU41L in every possible combination of server board, drive enclosure, hard drive, and peripheral. Sample combinations have been tested to gain added confidence in their inter-compatibility, and every device listed in this document has been tested in one or more configurations.

1.1 Test Overview

Testing performed of the RAID Controller SRCU41L is classified under two separate categories: Basic Compatibility Testing and Stress Testing.

1.1.1 Basic Compatibility Testing

Compatibility testing is performed with each supported operating system. Basic compatibility testing validates that the RAID controller can be used to install the operating system and that the base hardware feature set is functional. A small set of peripherals are used for installation purposes only. No additional add in cards are tested. Testing may include network connectivity and running of proprietary and industry standard test suites.

Note: The latest version of an operating system signifies the latest supported version at the time of the actual test run. New releases of this document may include a newly supported release of a given operating system. Previous releases of a supported operating system may not be tested beyond the basic compatibility test process.

1.1.1.1 Support Commitment for Basic Installation Testing

Intel commits to provide the following level of customer support for operating systems that receive only basic installation testing:

- Intel will provide and test operating system drivers for each of the server board's integrated controllers, provided that the controller vendor has a driver available upon request. Intel does not require vendors to develop drivers for operating systems that they do not already support. This may limit the functionality of certain server board integrated controllers.
- Intel will support customer issues that involve installation and/or functionality of an operating system with the server board's integrated controllers only if a driver has been made available.
- Intel will NOT provide support for issues related to use of any add-in adapters or peripherals installed in the server system when an operating system that received basic installation testing only is in use.
- Support is defined as assistance in root causing issues, and determining a customer acceptable resolution to the issue associated with the operating system. The resolution may include, but is not limited to, onboard controller driver changes, engaging the vendor for resolution, BIOS changes, firmware changes, or determining a customer acceptable workaround for the issue.

1.1.2 Adapter / Peripheral Compatibility and Stress Testing

Adapter / Peripheral Compatibility and Stress testing is performed only on the most current release of a supported operating system at the time of a given validation run. The Adapter / Peripheral Compatibility and Stress testing process consists of three areas:

- **Base Platform:** Each base platform will successfully install a given operating system, successfully run a disk stress test, and successfully run a network stress test.
- **Adapter Compatibility:** Adapter compatibility validation (CV) testing uses test suites to gain an accurate view of how the server performs with a wide variety of adapters under the primary supported operating systems. These tests are designed to show hardware compatibility between the cards and the server platform and include functional testing only. No heavy stressing of the systems or the cards is performed for CV testing.
- **Stress Testing:** This test sequence uses configurations that include add-in adapters in all available slots, (depending on chassis used) for a minimum 72-hour test run without injecting errors. Each configuration passes an installation test, a Network/Disk Stress test, and tape backup test. Any fatal errors that occur require a complete test restart.

1.1.2.1 Support Commitment for Adapter / Peripheral Compatibility and Stress Testing

Intel will provide the following level of customer support for operating systems that receive Adapter / Peripheral Compatibility and Stress testing:

- Intel will provide support for customer issues with these operating systems involving installation and/or functionality of the server board with or without the adapters and peripherals listed in this document as having been tested under the operating system.
- Support is defined as assistance in root causing issues, and determining a customer acceptable resolution to the issue associated with the operating system. The resolution may include, but is not limited to, onboard controller driver changes, engaging the vendor for resolution, BIOS changes, firmware changes, or determining a customer acceptable workaround for the issue.
- Intel will provide and test operating system drivers for each onboard video, network, and storage controller.
- Intel will enable vendors to provide driver support for add-in adapters using these operating systems.
- Intel will go through some of the steps to achieve certification to ensure its customers do not run across any problems, but the actual certification is the responsibility of the individual customer.

Note: Intel does not provide a support commitment for operating systems, adapter cards, and peripherals not listed in this document. Intel will consider support requests individually.

1.2 Pass/Fail Test Criteria

For each operating system, adapter, and peripheral configuration, a test passes if specific criteria are met. Specific configurations may have particular characteristics that are addressed on a case-by-case basis. In general, a configuration passes testing if the following conditions are met:

- The operating system installed without error.
 - Manufacturer's installation instructions or Intel's best-known methods were used for the operating system installation.
 - No extraordinary workarounds were required during the operating system installation.
 - The server system behaved as expected during and after the operating system installation.
 - Application software installed and executed normally.
- Hardware compatibility tests ran to completion without error.
- Test software suites executed successfully
 - Test and data files were created in the correct directories without error.
 - Files copied from client to server and back compare to the original without error.
 - Clients remain connected to the server system.
 - Industry standard test suites run to completion without error.

2. Intel® RAID Controller SRCU41L Firmware Configurations

The following table lists the controller / firmware configurations tested. This document will be updated with additional configurations as new revisions of the RAID Controller SRCU41L and/or firmware versions for that controller are released. Each configuration is assigned an identifier number that is referenced in the tables throughout this document.

Note: Intel will only support adapters and peripherals under the specified adapter configuration and operating systems versions with which they were tested

Base System Identifier #	Product Code	TA Number	Firmware Revision
1	SRCU41L	C88423-001	Ver. 314G
2	SRCU41L	C88423-002	Ver. 314H
3	SRCU41L		Ver. 314N
4	SRCU41L		Ver. 314P
5	SRCU41L		Ver. 314R

3. Operating Systems

The following table provides a list of supported operating systems for the Intel® RAID Controller SRCU41L. Each operating system was tested for compatibility with RAID Controller SRCU41L configuration listed in Section 2. Operating systems are supported only with the specified base system configuration(s) with which they were tested.

The following table also indicates whether each operating system received Basic Installation Testing, or Adapter / Peripheral Compatibility and Stress Testing. See Section 1 for information on the support commitments for Basic Installation Testing and Adapter / Peripheral Compatibility and Stress Testing.

Any variations to the standard operating system installation process are documented in the Installation Guidelines section of this document. If there are no installation guidelines noted in the following table, then the operating system installed as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: The operating systems listed below have been tested for compatibility with the RAID Controller SRCU41L but the operating system and its associated driver may not have been tested for compatibility with the server board you have chosen to use. See the supported operating system list for your server board to verify operating system support compatibility with the server board. Only currently shipping OS versions are tested with current firmware and driver versions. Older OS versions may not have been tested with current firmware and drivers. For support of older OS versions, the user may need to rely on an earlier version of the RAID controller firmware and driver.

Ident#	Operating System	Base System Configuration Tested and Type of Testing	Notes
1	Microsoft* Windows* 2003, Service Pack 1	Configuration 1, 2, 3, 4 – Compatibility and Stress	
2	Microsoft Windows Server 2003 Small Business Server	Configuration 1, 2 – Basic Installation	Application portion of the package was not tested and is not supported.
3	Microsoft Windows 2000 Advanced Server, Service Pack 5	Configuration 1, 2, 3, 4– Compatibility and Stress	
4	Microsoft Windows Small Business Server 2000	Configuration 1, 2 - Basic Installation	Application portion of the package was not tested and is not supported.
5	Microsoft Windows XP, SP2	Configuration 1, 2, 3, 4 – Compatibility and Stress	
6	Novell* NetWare* 5.1, SP8	Configuration 1 – Basic Installation	
7	Novell Netware 6.0, SP5	Configuration 1 – Basic Installation	
8	Novell NetWare 6.5, SP3	Configuration 1, 2, 3, 4 – Compatibility and Stress	
9	SCO* Open Server 5.0.7	Configuration 1, 2 – Basic Installation	

Intel® RAID Controller SRCU41L Tested Hardware and Operating System List
Operating Systems

Ident#	Operating System	Base System Configuration Tested and Type of Testing	Notes
10	SCO* UnixWare 7.1.3	Configuration 1 – Compatibility and Stress	
11	SCO UnixWare 7.1.4	Configuration 2 – Compatibility and Stress	
12	Red Hat* Enterprise Linux AS 3.0, U4	Configuration 1 – Compatibility and Stress	
13	Red Hat Enterprise Linux AS 3.0, U5	Configuration 2 – Compatibility and Stress	
14	Red Hat Enterprise Linux AS 4.0	Configuration 1, 2 – Compatibility and Stress	
15	SuSE* Linux Enterprise Server 9.0, SP1	Configuration 1, 2 – Compatibility and Stress	
16	SuSE Linux Professional 9.1	Configuration 1, 2 – Basic Installation	
17	SuSE Linux Professional 9.2	Configuration 1, 2 – Basic Installation	
18	Red Hat* Linux Professional 8.0	Configuration 1 – Basic Installation	
19	Red Hat Linux Professional 9.0	Configuration 2 – Basic Installation	
20	SuSE Linux Enterprise Server 8.0, SP3	Configuration 1 – Basic Installation	
21	SuSE Linux Professional 9.0	Configuration 2 – Basic Installation	
22	Microsoft Windows 2003, EM64T	Configuration 1, 2, 3, 4 – Compatibility and Stress	
23	Red Hat Enterprise Linux AS 3.0, EM64T, U4	Configuration 1 – Compatibility and Stress	
24	Red Hat Enterprise Linux AS 3.0, EM64T, U5	Configuration 2 – Basic Installation	
25	Red Hat Enterprise Linux AS 4.0, EM64T	Configuration 2 – Compatibility and Stress	
26	SuSE Linux Enterprise Server 9.0, EM64T SP1	Configuration 2 – Compatibility and Stress	
27	Microsoft Windows XP, EM64T	Configuration 1, 2, 3, 4 – Basic Installation	
28	SuSE Linux Enterprise Server 9.1, EM64T	Configuration 1, 2, 3 – Basic Installation	
29	Red Hat Enterprise Linux AS 3.0, EM64T, U6	Configuration 3 – Compatibility and Stress	
30	Red Hat Enterprise Linux AS 4.0, EM64T, U1	Configuration 3 – Compatibility and Stress	
31	Red Hat Enterprise Linux AS 4.0, EM64T, U2	Configuration 3, 4 – Compatibility and Stress	
32	Red Hat Enterprise Linux AS 4.0, U1	Configuration 3, 4 – Compatibility and Stress	
33	SuSE Linux Enterprise Server 9.0, EM64T SP2	Configuration 3, 4 – Compatibility and Stress	
34	SuSE Linux Enterprise Server 9.0, EM64T SP3	Configuration 3, 4 – Compatibility and Stress	

Ident#	Operating System	Base System Configuration Tested and Type of Testing	Notes
35	SuSE Linux Enterprise Server 9.0, SP2	Configuration 3, 4 – Compatibility and Stress	
36	SuSE Linux Enterprise Server 9.0, SP3	Configuration 3, 4 – Compatibility and Stress	
37	Red Hat Enterprise Linux AS 4.0, U2	Configuration 3, 4 – Compatibility and Stress	

3.1 Operating System Certifications

Listed below are the operating systems that Intel will certify with the Intel® RAID Controller SRCU41L. However, the customer is responsible for their own certification from the individual operating system vendors. In many cases, the customer may leverage their operating system certifications from Intel's testing. See the "Comment" section next to each operating system in the table below for additional information. Intel's certifications, pre-certification, and operating system testing may help reduce some of the risk in achieving customer certifications with the operating system vendors.

Operating System	Certification Listing	Comment
Microsoft* Windows* 2003 Enterprise Server	SRCU41L	OEM must request certification by Microsoft or their specific product. Search on SRCU41L http://www.microsoft.com/hwdq/hcl/search.asp http://developer.intel.com/design/servers/whql.htm
Microsoft Windows 2000 Advanced Server	SRCU41L	OEM must request certification by Microsoft for their specific product. Search on SRCU41L http://www.microsoft.com/hwdq/hcl/search.asp http://developer.intel.com/design/servers/whql.htm
Novell* NetWare* 5.1 and 6.0, 6.5	SRCU41L	Novell checks Intel's test results, certifies (if appropriate), and posts the certificate on their web site. The customer can leverage the Intel certification if the customer product meets the operating system vendor standard. http://developer.novell.com/yes

4. Intel® Server Boards

This list includes the Intel® Server Board software versions with which the server boards were configured at the time of testing.

Intel® Server Board	Microsoft® Windows* 2003	Microsoft® SBS 2003	Microsoft Windows 2000	Microsoft SBS 2000	Microsoft Windows XP	Red Hat® Linux v8.0	Red Hat Linux v9.0	Red hat Linux AS2.1	Red hat Linux AS3.0	Novell® NetWare® v6.5	SuSE® Linux ES 9.0 SP3	SuSE® Professional9.0	Open Server® 5.0.7	UnixWare® 7.1.3	UnixWare 7.1.4	Microsoft® Windows* 2003 x64	Microsoft Windows XP x64	Red hat Linux ES4.0 U2 x86_64	SuSE® Linux ES 9.0 SP3 x86_64
SE7520BD2 BIOS P3.1 BMC N/A FRU/SDR 6.4.1 HSC 1.12	X	X	X	X	X		X	X	X	X	X	X		X	X	X		X	X
SE7520AF2 BIOS P06 BMC 2.31 FRU/SDR N/A HSC 1.12	X	X	X	X	X		X	X	X	X	X	X	X	X	X	X		X	X
SE7320SP2 BIOS P05 BMC 2.40 FRU/SDR 1.20 HSC 1.12	X	X	X	X	X		X	X	X	X	X	X		X	X	X		X	X
SE7525GP2 BIOS P06 BMC 2.40 FRU/SDR 1.40 HSC N/A	X	X	X	X	X		X	X	X	X	X	X		X	X	X		X	X
SR7520JR2 BIOS P10 BMC 2.40 FRU/SDR N/A HSC 1.08	X	X	X	X	X		X	X	X	X	X	X		X	X	X		X	X
SE7320VP2 BIOS P04 BMC 2.40 FRU/SDR 1.70 HSC N/A	X	X	X	X	X		X	X	X	X	X	X		X	X	X		X	X
SE7221BK1-E BIOS P05 BMC 2.40 FRU/SDR 1.50 HSC N/A	X	X	X		X	X	X	X	X	X	X					X		X	X

Intel® RAID Controller SRCU41L Tested Hardware and Operating System List
Intel® Server Boards

Intel® Server Board	Microsoft® Windows* 2003	Microsoft® SBS 2003	Microsoft Windows 2000	Microsoft SBS 2000	Microsoft Windows XP	Red Hat® Linux v8.0	Red Hat Linux v9.0	Red hat Linux AS2.1	Red hat Linux AS3.0	Novell® NetWare® v6.5	SUSE® Linux ES 9.0 SP3	SUSE® Professional9.0	Open Server® 5.0.7	UnixWare® 7.1.3	UnixWare 7.1.4	Microsoft® Windows* 2003 x64	Microsoft Windows XP x64	Red hat Linux ES4.0 U2 x86_64	SUSE® Linux ES 9.0 SP3 x86_64
SE7221BA1-E BIOS BMC FRU/SDR HSC P0155 N/A N/A N/A	X		X		X		X		X	X	X					X		X	X
SE7320EP2 BIOS BMC FRU/SDR HSC P01 N/A N/A N/A	X		X		X		X		X	X	X					X		X	X
SE7520RP2 BIOS BMC FRU/SDR HSC P01 N/A N/A N/A	X		X		X		X		X	X	X					X		X	X
SE7230NH1-E BIOS BMC FRU/SDR HSC 0497P N/A N/A N/A	X															X		X	
S3000AH BIOS BMC FRU/SDR HSC R28 N/A N/A N/A	X										X					X		X	X
S5000VSA BIOS BMC FRU/SDR HSC R070 56 41 2.05	X										X					X		X	
S5000PAL/XAL BIOS BMC FRU/SDR HSC R070 56 41 2.02	X		X		X					X	X					X	X	X	X
S5000PSL / XSL / XVN BIOS BMC FRU/SDR HSC R070 56 41 2.05	X		X		X					X	X					X	X	X	X
S5000PSL / XSL / XVN BIOS BMC FRU/SDR HSC R057 50 31 N/A	X		X		X					X	X					X	X	X	X

Intel® RAID Controller SRCU41L Tested Hardware and Operating System List
 Intel® Server Boards

Intel® Server Board				Microsoft® Windows* 2003	Microsoft® SBS 2003	Microsoft Windows 2000	Microsoft SBS 2000	Microsoft Windows XP	Red Hat® Linux v8.0	Red Hat Linux v9.0	Red hat Linux AS2.1	Red hat Linux AS3.0	Novell® NetWare® v6.5	SUSE® Linux ES 9.0 SP3	SUSE® Professional9.0	Open Server® 5.0.7	UnixWare® 7.1.3	UnixWare 7.1.4	Microsoft® Windows* 2003 x64	Microsoft Windows XP x64	Red hat Linux ES4.0 U2 x86_64	SUSE® Linux ES 9.0 SP3 x86_64
BIOS R058	BMC 50	FRU/SDR V09	HSC N/A	X		X													X	X	X	X
S5000VCL																						

5. Enclosures, PCI Adapters, and Peripherals

Enclosure, add-in card, and peripheral testing was performed on the Intel® RAID Controller SRCU41L by Intel Labs, by independent test labs, or by the vendor. Compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred.

Although a large sample of configurations were tested, due to the large number of possible configurations, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility. Customers should see the Tested Hardware and Operating System List for the server board to verify that the device is included for the server board as well as for the RAID controller.

Add-in adapter card and peripheral compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred. The following table shows the operating system and base system configurations used to validate each device. The adapters are divided into categories based on their functionality. All integrated onboard devices are tested by default and are therefore not included in the following tables.

Note: Not all adapter cards and peripherals were tested under all operating systems.

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If there are no installation guidelines noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: Testing of adapters cards normally is performed with unused add-in adapters and onboard controller expansion ROMs disabled in BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and/or the onboard controllers when not booting from the controller or needing to use its built in utilities.

5.1 External Storage

Note: Enclosures are list ONLY if they were attached to the RAID Controller SRCU41L.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Dell*	PowerVault 201S		U160		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Dell*	PowerVault 211S		U160		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Dell*	PowerVault 220S		U320		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
StorCase*	S10A155		U320		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
StorCase*	S10A172		U320		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22

5.2 Internal Storage

Note: Enclosures are list ONLY if they were attached to the RAID Controller SRCU41L.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Intel®	SC5300		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SC5250-E		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SC5275-E		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SR1400		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SR1450		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SR2400		U320/SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22

5.3 CD-ROM Drives

Note: CD-ROM drives are listed ONLY if the operating system was installed from this device.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Sony*	CDU5211	CDU5211	IDE		1, 3, 6, 7, 8, 9, 10
Panasonic*	AXXDVDFloppy	SR-8177-B	IDE		1, 3, 6, 7, 8, 9, 10

5.4 Tape Drives

Note: Tape drives are listed ONLY if they were attached to the RAID Controller SRCU41L.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Sony*	SDX-500	SDX-500C/TB	Ultra2/wide		1, 3, 6, 9
Sony*	PCBacker II	SDT-11000/PB	Ultra2/wide		1, 3, 6, 7, 8, 9, 10
Seagate *	SCORPION 40		SCSI DDS4 DAT		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Quantum*	DLT8000				1, 3, 6, 9
Sony*	SDT 9000				3, 5, 6, 8, 10
Seagate*	SCORPION 24	STD2401LW	DDS4 DAT		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22

5.5 Hard Disk Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Adaptec*	ASC-39320	ASC-39320	PCI-X* 133		1, 3, 6, 7, 8, 9, 10
Adaptec*	ASC-39160	ASC-39160	PCI 64/66		3, 5, 6, 8, 10
Emulex*	LightPulse LP9402	LP9402	FC-HBA PCI 64/66		1, 3, 6, 7, 8, 9, 10
LSI Logic*	LSI20160	LSI20160	PCI 64/66		1, 3, 6, 9
LSI Logic*	LSI20160L	LSI20160L	PCI 64/66		1, 3, 6, 9
QLogic*	QLA2200L	QLA2200L	PCI 64/66		1, 3, 6, 7, 8, 9, 10

5.6 SCSI RAID Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Adaptec*	SCSI RAID 2120S	ASR-2120S	PCI 64/66		3, 5, 6, 8, 10
Adaptec*	SCSI RAID 2200S	ASR-2200S/64MB	PCI 64/66		1, 3, 6, 9
Adaptec*	SCSI RAID 3410S	ASR-3410S	PCI 64/66		1, 3, 6, 9
ICP-Vortex*	GDT4523RZ	GDT4523RZ	PCI 32/66		3, 5, 6, 8, 10
ICP-Vortex*	GDT6523RS	GDT6523RS	PCI 32/33		3, 5, 6, 8, 10
ICP-Vortex*	GDT8623RZ	GDT8623RZ	PCI 64/66		1, 3, 6, 9, 11
ICP-Vortex*	GDT8663RZ	GDT8663RZ	PCI 64/66		1, 3, 6, 9, 11
Intel®	SRCU31L	SRCU31LA	PCI 32/33		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SRCU31	SRCU31A	PCI 64/33		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SRCZCR	SRCZCR	PCI 64/66		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SRCU32	SRCU32U	PCI 64/66		1, 3, 6, 9, 11, 15, 16, 17, 18, 19, 20
Intel®	SRCU42L	SRCS42L	PCI 64/66		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel®	SRCS16	SRCS16	PCI 64/66		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	SRCZCRX	SRCZCRX	PCI-X*		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	SRCU42E	SRCU42E	PCI Express*		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	SRCU42X	SRCU42X	PCI-X		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	SRCS28X	SRCS28X	PCI-X		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28

5.7 Network Interface Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Intel®	PRO/100+ S Server	PILA8470D3G1P20	PCI 32/33		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	Pro/100 S Server	PILA8470D3G1L	PCI 32/33		3, 5, 6, 8, 10
Intel®	Pro/100 S Dual Port Server Adapter	PILA8472D3G1P	PCI 64/33		1, 3, 6, 9
Intel®	PRO/1000XT Gigabit Server Adapter	PILA8490XTP20	PCI-X 133		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel®	PRO/1000T	PWLA8490T	PCI 64/66		1, 3, 6, 9
Intel®	Pro/1000 XT Server Adapter	PWLA8490XT	PCI-X 133		3, 5, 6, 8, 10
Intel®	Pro/1000 XT Server Adapter	PWLA8490XTL	PCI-X 133		3, 5, 6, 8, 10
Intel®	Pro/1000 MF Server Adapter	PWLA8492MF	PCI-X 133		1, 3, 6, 9
Intel®	PRO/1000MT Dual Port Server Adapter	PWLA8492MT	PCI-X 133		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28

6. Hard Disk Drives

Enclosure, add-in card, and peripheral testing was performed on the Intel® RAID Controller SRCU41L by Intel Labs, by independent test labs, or by the vendor. The RAID Controller SRCU41L compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred. Although a large sample of configurations was tested, due to the large number of possible configurations, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility. Customers should see the Tested Hardware and Operating System List for the server board to verify that the device is included for the server board as well as for the RAID Controller SRCU41L.

Add-in adapter card and peripheral compatibility and stress testing will only be performed with the latest version of an operating system at the time the validation testing occurred. The following table shows the operating system and base system configurations used to validate each device. The adapters are divided into categories based on their functionality. All integrated onboard devices are tested by default and are therefore not included in the following tables.

Note: Not all adapter cards and peripherals were tested under all operating systems.

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If there are no installation guidelines noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: Testing of adapters cards normally is performed with unused add-in adapters and onboard controller expansion ROMs disabled in BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and/or the onboard controllers when not booting from the controller or needing to use its built-in utilities.

6.1 Hard Disk Drives

Note: Hard disk drives are listed ONLY if they were attached to the RAID Controller SRCU41L during testing.

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Fujitsu*		MAP3147NC	U320	10 K	147 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu*	Allegro 5	MAG3182LC	U160/SCA	10 K	18 GB	1, 3, 6, 9
Fujitsu*	Allegro 7LX	MAM3184MC	U160/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Fujitsu*		MAS3184NC	U320	15 K	18 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu*	Allegro 7 LE	MAN3367MC	U160/SCA	10 K	37 GB	1, 3, 6, 7, 8, 9, 10
Fujitsu*		MAP3367NC	U320	10 K	37 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 25, 26, 27, 28
Fujitsu*		MAS3367NC	U320	15 K	37 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu*		MAP3735NC	U320	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22

Intel® RAID Controller SRCU41L Tested Hardware and Operating System List
Hard Disk Drives

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Fujitsu*		MAS3735NC	U320	15 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu*	Allegro 5 LE	MAE3091LC	U160/SCA	15 K	9 GB	3, 5, 6, 8, 10
Hitachi*	Ultrastar 146Z10	IC35L146UCDY10-0,	U320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi*	Ultrastar 146Z10	IC35L018UCDY10-0	U320/SCA	10 K	18 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi*	Ultrastar 146Z10	IC35L036UCDY10-0	U320/SCA	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi*	Ultrastar 146Z10	IC35L073UCDY10-0	U320/SCA	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi*	Ultrastar 10K300	HUS103030FL3800	U320/SCA	10 K	300 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,32
Hitachi*	Ultrastar 10K300	HUS103014FL3800	U320/SCA	10 K	147 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,37
Hitachi*	Ultrastar 10K300	HUS103073FL3800	U320/SCA	10 K	73 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,34
Hitachi*	Ultrastar 15K147	HUS151414FL3800	U320/SCA	15 K	147 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,33
Hitachi*	Ultrastar 15K147	HUS151473FL3800	U320/SCA	15 K	73 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,36
Hitachi*	Ultrastar 15K147	HUS151436FL3800	U320/SCA	15 K	36 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,32
IBM*	UltraStar 146ZN	IC35L146UCDY10-0	U320/SCA	10 K	146 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30, 31,35
IBM*	UltraStar 36Z15	IC35L018UCPR15	U160/SCA	15 K	18 GB	3, 5, 6, 8, 10
IBM*	UltraStar 73LZX	IC35L036UCD210	U160/SCA	10 K	36 GB	1, 3, 6, 9
Maxtor*	Atlas 10K IV	8B146L0	U320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 27, 28
Maxtor*	Atlas 10K IV	8B146J0	U320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor*	Atlas 10K III-U320	KU18J017	U320/SCA	10 K	18 GB	1, 3, 6, 9
Maxtor*	Atlas 10K III-U320	KU18J07E	U320/SCA	10 K	18 GB	3, 5, 6, 8, 10
Maxtor*	Atlas 10K IV	8B036L0	U320	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor*	Atlas 10K IV	8B036J0	U320/SCA	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor*	Atlas 10K III-U320	KU73J017	U320/SCA	10 K	73 GB	1, 3, 6, 9
Maxtor*	Atlas 10K IV	8B073L0	U320	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor*	Atlas 10K IV	8B073J0	U320/SCA	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Quantum*	Atlas 10K III	KW18J014	U320/SCA	10 K	18 GB	3, 5, 6, 8, 10
Quantum*	Atlas 10K III	KW36J011	U160/SCA	10 K	36 GB	1, 3, 6, 9

Intel® RAID Controller SRCU41L Tested Hardware and Operating System List
Hard Disk Drives

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Quantum*	Atlas IV	KN09J011	U160/SCA	7.2 K	9 GB	1, 3, 6, 7, 8, 9, 10
Quantum*	Atlas IV	KN09L011	U160/Wide	7.2 K	9 GB	1, 3, 6, 7, 8, 9, 10
Seagate*	Cheetah 73	ST173404LC	U160/SCA	10 K	73 GB	3, 5, 6, 8, 10
Seagate*	Cheetah 36ES	ST318406LC	U160/SCA	10 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate*	Cheetah X15	ST318451LC	U160/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate*	Cheetah X15	ST318432LC	U320/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate*	Cheetah X15	ST318452LC	U160/SCA	15 K	18 GB	1, 3, 6, 9
Seagate*	Cheetah 15K.3	ST318453LC	U320/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17
Seagate*	Cheetah 73LP	ST336605LC	U160/SCA	10 K	36 GB	1, 3, 6, 9
Seagate*	Cheetah 10K.6	ST336607LC	U320/SCA	10 K	36 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Seagate*	Cheetah 10K.6	ST3146807LC	U320/SCA	10 K	146 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Seagate*		ST336732LC	U320/SCA	15 K	36 GB	1, 3, 5, 7, 11, 15, 16, 177, 18, 19, 21, 21, 22
Seagate*		ST336432LC	U320/SCA	15 K	36 GB	1, 3, 5, 7, 11, 15, 16, 177, 18, 19, 21, 21, 22
Seagate*	Cheetah 15K.3	ST373453LC	U320/SCA	15 K	73 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22
Seagate*	Barracuda 18XL	ST39236LC	U160/SCA	7.2 K	9 GB	1, 3, 6, 9
Seagate*	Cheetah 18XL	ST39204LC	U160/SCA	10 K	9 GB	1, 3, 6, 7, 8, 9, 10
Seagate*	Barracuda 18XL	ST39236LC	U160/SCA	7.2 K	9 GB	1, 3, 6, 9
Seagate*	10K7	ST3300007LC	U320/SCA	10 K	300 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37
Seagate*	10K7	ST3146707LC	U320/SCA	10 K	146 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37
Seagate*	10K7	ST373207LC	U320/SCA	10 K	73 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37
Seagate*	15K4	ST3146854LC	U320/SCA	15 K	146 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37
Seagate*	15K4	ST373454LC	U320/SCA	15 K	73 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37
Seagate*	15K4	ST336754LC	U320/SCA	15 K	36 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35, 36, 37