## **Safety Non Contact Switch**

Based on Magnetic Coded Technology

## FF-SNC Series



### **FEATURES**

- Meets applicable parts of European EN 1088 standard for Interlocking devices associated with guards
- Permanent self-checking electronic designed in compliance with the requirements of the EN 954-1 standard for Category 3 protective Devices
- Operating range:
   5 mm 7 mm / 0.20 in 0.27 in ON,
   8 mm 12 mm / 0.32 in 0.47 in OFF
- High resistance to environmental influences
- ABS and Stainless Steel housings sensors available
- · Sensors sealing: IP 67
- Prewired or M8 plug termination
- Supply voltage: 24 Vdc/Vac ±15 %;
   110 Vac ±15 % (only available for the 4-sensor control unit)
- Response time of the control unit:
  15 ms
- · Manual or automatic restart
- · LED status indicator
- 2-sensor control unit: (DIN rail mount 22,5 mm / 0.89 in width)

4-sensor control unit: (DIN rail mount 75 mm / 2.95 in width)

5-sensor extension module: (DIN rail mount 22,5 / 0.89 in width)

### TYPICAL APPLICATIONS

Interlocking guard for non locked mechanical screens offering free access (machines must achieve instant stop):

- Machine door or casting "open/closed" detection
- Guard-in-place detection, gate/access door detection
- Control of mechanical screens used in addition to a safety light curtain
- Food & Beverage, Packaging, Machine Tool, Automotive and Textile.



\*New: M8 plug model now available

The FF-SNC Honeywell safety non contact switch is a tamper resistant safety system for monitoring machine guards. The actuator being a passive component, the safety switch is the only component that needs to be wired to the control unit and cannot be defeated by regular magnet.

Each system is made up of one or several safety switches, actuators and a control unit. The Honeywell FF-SNC safety non contact switches are designed in compliance with the requirements of the EN 954-1 European Standard for Category 3 Protective Devices.

The FF-SNC is especially suited for applications where perfect door alignment can not be obtained. The FF-SNC Series can be mounted on sliding, hinged or removable machine guards. The output of the control unit is triggered as soon as the distance between the safety switch and the actuator is greater or equal to 8 mm / 0.32 in. This switching distance compensates for the machine vibration or any issue with the installation alignment.

The sensor and actuator small size makes it usable under tight space requirements.

The safety switches and the actuators provide excellent chemical and mechanical resistance. Stainless steel housing versions fulfil the requirements of the Food and Beverage industry.

The FF-SNC400 safety control unit comes in a 75 mm / 2.95 in package and can monitor up to 4 sensors.

The FF-SNC200R2 safety control unit with its 22,5 mm / 0.89 in width will easily find a place in the electrical cabinet and can monitor 2 sensors. Both control units can be placed up to 100 m / 328 ft away from the safety non contact switches. The indicators located on the front cover of both control units provide individual door status information.

The FF-SNC1EXT extension module can be added to the FF-SNC400 or FF-SNC200 control unit and allows the connection of 5 additional sensors.



### MISUSE OF DOCUMENTATION

- The information presented in this product sheet (or catalogue) is for reference only. DO NOT USE this document as system installation information.
- Complete installation, operation and maintenance information is to be referenced for each product.

Failure to comply with these instructions could result in death or serious injury.


# **Safety Non Contact Switch FF-SNC**


- Complies with the requirements of the EN 954-1 for Category 3 equipment
- Meets applicable parts of ANSI/RIA/OSHA regulations

Dimensions in millimeters / inches, meters / feet, weights in kg / lbs




ABS (FF-SNC1SADDPA-D) or Stainless Steel 316 and Resin filled (FF-SNC1SADDPS	
5 mm - 7 mm / 0.20 in - 0.27 in ON • 8 mm - 12 mm / 0.32 in - 0.47 in OFF	
allowable misalignment: ±4mm / ±1/6 in	
1 mm	
Prewired 3 m / 9.84 ft or 5 m/16.4 ft (ABS only) - M8 plug: 5 mm/16.4 ft (ABS only)	
Operating: -10 °C to +55 °C/14 °F to 131 °F • Storage: -20 °C to +60 °C/-4 °F to 140 °	
Max. cable length: 100 m / 328 ft	
IP 67 prewired or M8 plug	
2 x (M4 x 20 mm) Tamper proof screws (supplied with the product)	
Category 3 according to EN 954-1	
24 Vdc/Vac ±15 % • 110 Vac ±15 % (FF-SNC400RE only)	
15 ms (with or without extension module)	
6 VA (with or without ext. module): FF-SNC400 • 3 VA (with or without ext. module): FF-SNC20	
Operating: -10 °C to + 55 °C / 14 °F to 131 °F • Storage: -20 °C to 60 °C / -4 °F to 140 °F	
Output 2 NO + 1 NC relay contact	
Max.: 4 A / 230 Vac; 2 A / 24 Vdc (Res.) @Cos = 1 • Min.: 10 V / 10 mA	
Manual or automatic	
IP 40 Housing, Terminals IP 20	
35 mm / 1.37 in DIN rail	
FF-SNC200R2 control unit: Power, Run and 2 guard status indicators	
FF-SNC400RE control unit: 4 guard status indicators and deselect indicators	
Polycarbonate, red	






	а	b	С
ABS	52 / 2.04	28 / 1.10	14 / 0.55
SS316	53 / 2.8	29 / 1.14	13.5 / 0.53

M4 x 20 mmTorx screws are supplied with the switches.





## ■ Safety Distance Calculations per EN 294 European standard

The dimensions of openings correspond to the narrowest dimension of a slot opening (for openings greater than 120 mm / 4.72 in, refer to the EN 294 standard).

Safety distances sr for regular openings for persons of 14 years of age and above:

Part of body	Illustration	Opening size	Safety distance sr
			Slot
Fingertip	k.A	e ≤ 4	≥ 2
	Ann.	4 < e ≤ 6	≥ 10
	Ye of		
Finger up to knuckle joint	201	6 < e ≤ 8	≥ 20
	(m)	8 < e ≤ 10	≥ 80
Or	No. i	10 < e ≤ 12	≥ 100
	me to	12 < e ≤ 20	≥ 120
hand		20 < e ≤ 30	≥ 850*
Arm up to junction with shoulder		30 < e ≤ 40	≥ 850
	7/2×1	40 < e ≤ 120	≥ 850

<sup>\*</sup>If the length of the slot opening is ≤ 65 mm / 2.56 in, the thumb will act as a stop and the safety distance can be reduced to 200 mm / 7.88 in). For more information on the guards installation, refer to the European standards: EN 811, EN 953, EN 294

## ■ Safety Distance Calculations per US ANSI / OSHA standard

$$Ds = K(Ts + Tc + Tr) + Dpf$$

With:

Ds = minimum safe distance between safeguarding device and hazard

K = speed constant: 1,6 m/sec (63 in/sec) minimum based on the movement being the hand/arm only and the body being stationary (a greater value may be required in specific applications and when body motion must also be considered)

*Ts* = worst stopping time of the machine/equipment

*Tc* = worst stopping time of the control system

Tr = response time of the safeguarding device including its interface (Tr for interlocked barrier may include a delay due to actuation. This delay may result in Tr being a deduct—negative value).

Dpf = the "Depth penetration factor" is the maximum travel towards the hazard if the guard can be opened a certain width or amount before a stop is signaled.

### Dpf values from OSHA 0-10 Table:

If the maximum width or diameter of the opening is less than or equal to (mm/in)	Dpf equals (mm/in)
6,4 / 0.25	12,7 / 0.5
9,5 / 0.375	38,1 / 1.5
12,7 / 0.5	63,5 / 2.5
15,9 / 0.625	88,9 / 3.5
19,1 / 0.75	139,7 / 5.5
22,2 / 0.875	165,1 / 6.5
31,8 / 1.25	190,5 / 7.5
38,1 / 1.5	317,5 / 12.5
47,6 / 1.875	393,7 / 15.5
54 / 2.125	444,5 / 17.5

Note: Over 54 mm / 2.125 in, the Dpf equals 800 mm / 31.5 in, with a maximum allowable opening of 152,4 mm / 6 in.


Example: Dpf = 0 when the guard can be opened up to, but less than 6,4 mm / 0.25 in before issuing a stop command. Dpf = 444,5 mm / 17.5 in if the guard can be opened 54,0 mm / 2.125 in.

At no time can the opening be greater than 152,4 mm / 6 in before issuing a stop command.


For more information, refer to the US regulations and standards (OSHA 29 CFR 1910.212 & 1910.217, ANSI B11.19 and ANSI/RIA R15.06).

## **■** Connection diagram:


# FF-SNC200R2 Control Unit (Manual reset option)



FF-SNC400R2/FF-SNC400RE Control Unit (Manual reset option)




FF-SNC1EXT Extension Module (can be used with FF-SNC400 or FF-SNC200 Series, 24 Vac/dc only)




Up to 28 gates can be monitored using 6 extension modules with the FF-SNC400R2. The extension module can only be used with the 24 Vac/dc control units.

### **■** LED indicators:


## FF-SNC200R2 Control Unit



## FF-SNC400R2/FF-SNC400RE Control Unit



## FF-SNC1EXT Control Unit



## Ordering information

Part number	Description	Weight
FF-SNC200R2	24 Vdc/Vac Control unit for monitoring up to 2 gates	Max. 183 g / 0.403 lb
FF-SNC400R2	24 Vdc/Vac Control unit for monitoring up to 4 gates	Max. 575 g / 1.26 lb
FF-SNC400RE	110 Vac Control unit for monitoring up to 4 gates	Max. 575 g / 1.26 lb
FF-SNC1EXT	Extension module	Max. 135 g / 0.297 lb
FF-SNC1SA03PA	Safety switch + actuator, 3 m / 9.84 ft cable, ABS housing	Max. 150 g / 0.330 lb
FF-SNC1SA05PA	Safety switch + actuator, 5 m / 16.40 ft cable, ABS housing	Max. 200 g / 0.441 lb
FF-SNC1SA03PS	Safety switch + actuator, 3 m / 9.84 ft cable, stainless steel 316 housing	Max. 250 g / 0.551 lb
FF-SNC1SA05PS	Safety switch + actuator, 5 m / 16.40 ft cable, stainless steel 316 housing	Max. 300 g / 0.662 lb
FF-SNC1SA05PA-QD	Safety switch + actuator + M8 cordset, 5 m / 16.40 ft cable, ABS housing	Max. 350 g / 0.771 lb
FF-SNC1SA05PS-QD	Safety switch + actuator + M8 cordset, 5 m / 16.40 ft cable, stainless steel 316 housing	Max. 450 g / 0.992 lb
FF-SNC1SA-050-CBL	Single core cable, 50 m/ 164 ft roll	Max. 1,5 kg / 3.307 lbs

### Warranty and remedy

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose.

While we provide application assistance, personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change at any time without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

#### Sales and Service

Honeywell serves its customers through a worldwide network of sales offices and distributors. For application assistance, current specifications, pricing or name of the nearest Authorised Distributor, contact a nearby sales office or:

INTERNET: www.honeywell.com/sensing

E-mail: info.sc@honeywell.com

#### **ASIA PACIFIC**

Control Products Asia Pacific Headquarters Phone: +(65) 6355-2828 Fax: +(65) 6445-3033

Australia Honeywell Limited Phone: +(61) 2-9370-4500 Fax: +(61) 2-9370-4525 Toll Free 1300-36-39-36

Toll Free Fax: 1300-36-04-70

China - PRC - Beijing Honeywell China Inc Phone: +(86-10) 8458-3280 Fax: +(86-10) 8458-3102

China - PRC - Shanghai Honeywell China Inc. Phone: (86-21) 6237-0237 Fax: (86-21) 6237-1237

China - Hong Kong S.A.R. Honeywell Ltd. Phone: +(852) 2953-6412 Fax: +(852) 2953-6767

Indonesia

Honeywell Indonesia Pte Ltd. Phone: +(62) 21-535-8833 Fax: +(62) 21-5367-1008

India

TATA Honeywell Ltd. Phone: +(91) 20 687 0445/0446 Fax: +(32) 2 728 2502 Fax: +(91) 20 681 2243/687 5992

Japan

Honeywell Inc Phone: +(81) 3 5440 1425 Fax: +(81) 3 5440 1368

South Korea Honeywell Korea Co Ltd Phone: +(822) 799-6167 Fax: +(822) 792-9013

Malavsia

Honeywell Engineering Sdn Bhd Phone: +(60-3) 7958-4988 Fax: +(60-3) 7958-8922

New Zealand

Honeywell Limited Phone: +(64-9) 623-5050 Fax: +(64-9) 623-5060 Toll Free (0800) 202-088

**Philippines** 

Honeywell Systems (Philippines) Inc. Phone: +(63-2) 636-1661/1662 Fax: +(63-2) 638-4013

Singapore

Honeywell South East Asia Phone: +(65) 6355-2828 Fax: +(65) 6445-3033

Thailand

Honeywell Systems (Thailand) Ltd. Phone: +(662) 693-3099 Fax: +(662) 693-3085

Taiwan R.O.C. Honeywell Taiwan Ltd. Phone: +(886-2) 2245-1000 Fax: +(886-2) 2245-3242

FUROPF

Austria

Honeywell Austria GmbH Phone: +(43) 1 727 80 366/246 Fax: +(43) 1 727 80 337

**Belgium** Honeywell SA/NV Phone: +(32) 2 728 2522

Bulgaria Honeywell EOOD

Phone: +(359) 2 979 00 23 Fax: +(359) 2 979 00 24

Czech Republic Honeywell spol. s.r.o. Phone: +(420) 242 442 111 Fax: +(420) 242 442 182

Honeywell A/S Phone: +(45) 39 55 55 55 Fax: +(45) 39 55 55 58

Finland Honeywell OY Phone: +(358) 9 3480101 Fax: +(358) 9 34801375

France

Honeywell SA Phone: +(33) 1 60 19 80 40 Fax: +(33) 1 60 19 81 73

Germany Honeywell AG

Phone: +(49) 69 8064 444 Fax: +(49) 69 8064 442

Hungary

Honeywell Kft. Phone: +(36 1) 451 4300 Fax: +(36 1) 451 4343

Honeywell S.p.A. Phone: +(39) 02 92146 450/ Fax: +(39) 02 92146 490

The Netherlands Honeywell B.V.

Phone: +(31) 20 565 69 11 Fax: +(31) 20 565 66 00

Norway Honeywell A/S

Phone: +(47) 66 76 20 00 Fax: +(47) 66 76 20 90

Poland Honeywell Sp. zo.o

Phone: +(48)606 0964 Fax: +(48)606 0901

Honeywell Portugal Lda Phone: +(351 21) 424 50 00 Fax: +(351 21) 424 50 99

Romania

Honeywell Bucharest Phone: +(40) 21 231 64 37/38 Fax: +(40) 21 231 6439

Commonwealth of Independent States (CIS) Z.A.O. Honeywell Phone: +(7 095) 796 98 36

Fax: +(7 095) 796 98 93

Slovak Republic Honeywell s.r.o. Phone: +(421 2) 58 247 403 Fax: +(421 2) 58 247 415

South Africa (Republic of)

Honeywell Southern Africa Honeywell S.A. Pty. Ltd Phone: +(27) 11 805 1201 Fax: +(27) 11 805 1504

Spain

Honeywell S.A. Phone: +(34) 91 313 6100 Fax: +(34) 91 313 6129

Sweden

Honeywell AB Phone: +(46) 8 775 55 00 Fax: +(46) 8 775 56 00

Switzerland

Honeywell AG Phone: +(41) 1 855 24 40 Fax: +(41) 1 855 24 45

Turkey

Honeywell Turkey A.S. Phone: +(90) 216 575 6620 Fax: +(90) 216 575 6637

Ukraine

Honeywell Phone: +(380) 44 201 44 74 Fax: +(380) 44 201 44 75

United Kingdom

Honeywell Control Systems Ltd Phone: +(44) 1698 481481 Fax: +(44) 1698 481676

Mediterranean & African Distributors

Honeywell SpA Phone: +(39) 2 921 46 232 Fax: +(39) 2 921 46 233

Middle East Headquarters Honeywell Middle East Ltd. Phone: +(9712) 443 2119 Fax: +(9712) 443 2536

NORTH AMERICA

USA/Canada Honeywell

Control Products, International Headquarters Phone: 1-800-537-6945 1-815-235-6847 Fax: 1-815-235-6545 E-mail: info.sc@honeywell.com

LATIN AMERICA

Honeywell Latin America Headquarters

Phone: 1-305-805-8188 Fax: 1-305-883-8257

Argentina

Honeywell S.A.I.C. Phone: +(54-11) 4383-3637 Fax: +(54-11) 4325-6470

Brazil

Honeywell do Brasil & Cia Phone: +(55-11) 4166-1900 Fax: +(55-11) 4166-1901

Honeywell Chile, S.A. Phone: +(56-2) 425-8400 Fax: +(56-2) 425-8410

Honeywell S.A. de C.V. Phone: +(52) 55 5081-0200 Fax: +(52) 55 5081-0202

Puerto Rico, Caribbean Honeywell Inc.

Phone: +(809) 792-7075 Fax: +(809) 792-0053

Venezuela Honevwell CA

Phone: +(58-212) 273-0511 Fax: +(58-212) 273-0599

This publication does not constitute a contract between Honeywell and its customers. The contents may be changed at any time without notice. It is the customer's responsibility to ensure safe installation and operation of the products. Detailed mounting drawings of all products illustrated are available on request.

© 2002 - 2004 Honeywell International Inc. All rights reserved.

Honeywell

Honeywell

21 Chemin du Vieux Chêne 38240 Meylan Cedex France

Honeywell

11 West Spring Street Freeport, Illinois 61032 USA

107097-13-EN FR26 GLO 204 Printed in France

www.honeywell.com/sensing