<u>OPTO 22</u>

DATA SHEET Form 730-050728

Description

The B200 is an analog brain board used to control up to 16-channels of remote analog I/O using Opto 22's Classic analog I/O mounting racks and modules. On-board intelligence enables many distributed control features. The B200 and its digital counterpart, the B100, can be used with either an Opto 22 controller or a host computer.

The B200 communicates serially via RS-485 at communication speeds up to 115K baud using the Mistic[®] protocol. The B200 brain board is physically interchangeable with the traditional B2 Optomux brain boards for Opto 22 Classic I/O and is plug-compatible with Classic racks. This compatibility makes it possible for a "Classic I/O customer" using Standard analog I/O to take advantage of the increased performance of Opto 22's Mistic communications protocol. The compatibility also allows Optomux users to migrate to Opto 22's FactoryFloor[®] software without modifying existing field or communication wiring.

Utilizing the Mistic protocol, faster communication speed is combined with advanced I/O processing to provide unmatched performance and power at the I/O level. Time-critical functions such as temperature conversion and linearization, digital filtering, max/min tracking, and averaging can be offloaded from your host processor to the B200's intelligent I/O processor. Distributed control functions include event/reactions, which execute highspeed, deterministic responses to sophisticated control sequences, alarm monitors, or diagnostic conditions. In addition, the B200 can generate an

interrupt signal to an Opto 22 controller or host computer notifying the controller that an event has occurred.

For systems I/O customers, the B200 is the gateway to Opto 22's FactoryFloor. FactoryFloor consists of these integrated components:


Part

- OptoControl[™], a graphical, flowchart-based development environment for real-time control solutions.
- OptoDisplay[™], a graphical, multimedia operator interface package.
- OptoServer[™], an OPC 1.0-compliant data server that connects the controller network with the PC-based FactoryFloor network.

Opto 22's OptoDriver Toolkit[™] allows you to create custom solutions utilizing the B200. The OptoDriver toolkit includes 32-bit Windows-compatible drivers, Windows 16-bit drivers, and Opto 22's classic DOS drivers. The kit also provides files, documentation, and real-world examples needed to write Microsoft Windows and DOS software applications that can access Opto 22 I/O hardware, using high-level languages such as Microsoft Visual C++[™] or Microsoft Visual Basic[®]. The OptoDriver Toolkit provides programmers with a simple, direct connection to Opto 22's industry-standard Mistic, Optomux, or Pamux[®] I/O systems.

BRAINS CLASSIC/MISTIC 16-CHANNEL ANALOG

Number Description B200 16-Channel Analog Brain, Mistic Protocol



page 1/10

OPTO 22 DATA SHEET


Form 730-050728

BRAINS CLASSIC/MISTIC 16-CHANNEL ANALOG

page 2/10

Description (Continued)

B100/B200 System Architecture



Analog
PID Loop Control
High/Low Limit Monitoring
Thermocouple Linearization
Digital Filtering
Ramping/Waveform Generation
Programmable Offset and Gain
Engineering Unit Scaling
Square Root Extraction

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • Phone: (951) 695-3000 • (800) 321-OPTO • Fax: (951) 695-3095 • www.opto22.com

OPTO 22

BRAINS CLASSIC/MISTIC 16-CHANNEL ANALOG

DATA SHEET Form 730-050728

page 3/10

Specifications

MISTIC Command Set - Analog Functions

Analog Setup/System Commands

IDENTIFY TYPE POWER-UP CLEAR REPEAT LAST RESPONSE RESET RESET ALL PARAMETERS TO DEFAULT SET COMM LINK WATCHDOG AND DELAY SET COMM LINK WATCHDOG TIME-OUT DATA SET RESPONSE DELAY SET SYSTEM OPTIONS

Analog I/O Configuration Commands

CALCULATE AND SET ADC MODULE OFFSET CALCULATE AND SET ADC MODULE GAIN READ MODULE CONFIGURATION SET ADC MODULE OFFSET SET ADC MODULE GAIN SET AVERAGING SAMPLE WEIGHT SET CHANNEL CONFIGURATION SET ENGINEERING UNIT SCALING PARAMETERS SET I/O CONFIGURATION - GROUP SET TOTALIZATION SAMPLE WEIGHT SET TPO RESOLUTION STORE SYSTEM CONFIGURATION

Analog Read/Write/Output Commands

RAMP DAC OUTPUT TO ENDPOINT READ AND CLEAR I/O MODULE DATA READ AND CLEAR I/O MODULE DATA - GROUP READ I/O MODULE MAGNITUDE READ I/O MODULE MAGNITUDE - GROUP SET DAC MODULE MAGNITUDE, ENG. UNITS SET DAC MODULE MAGNITUDE, ENG. UNITS - GROUP SET DAC MODULE MAGNITUDE, COUNTS SET DAC MODULE MAGNITUDE, COUNTS - GROUP

Analog Event/Reaction Commands

CLEAR EVENT/REACTION TABLE CLEAR EVENT TABLE ENTRY CLEAR INTERRUPT ENABLE/DISABLE EVENT ENTRY - GROUP ENABLE/DISABLE EVENT TABLE ENTRY READ AND CLEAR EVENT LATCHES READ EVENT DATA HOLDING BUFFER READ EVENT ENTRY ENABLE/DISABLE STATUS READ EVENT LATCHES READ AND OPTIONALLY CLEAR EVENT LATCH READ EVENT TABLE ENTRY SET EVENT INTERRUPT STATUS SET EVENT ON COMM LINK WATCHDOG TIME-OUT SET EVENT ON I/O >= SETPOINT SET EVENT ON I/O <= SETPOINT SET EVENT REACTION COMMAND

Analog PID Loop Commands

INITIALIZE PID LOOP READ ALL PID LOOP PARAMETERS READ PID LOOP PARAMETER SET PID LOOP CONTROL OPTIONS SET PID LOOP DERIVATIVE RATE SET PID LOOP GAIN SET PID LOOP GAIN SET PID LOOP INTEGRAL RESET RATE SET PID LOOP MIN-MAX OUTPUT LIMITS SET PID LOOP MIN-MAX SETPOINT LIMITS SET PID LOOP PROCESS VARIABLE SET PID LOOP SETPOINT

1. For detailed information about Mistic Command Set, refer to Mistic Protocol

- User's Guide (Form #270) or Misticware[™] User's Guide (Form #522).
- 2. For detailed information about Optomux Command Set, refer to Optomux Protocol

Guide (Form #1572).

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • Phone: (951) 695-3000 • (800) 321-OPTO • Fax: (951) 695-3095 • www.opto22.com

OPTO 22

BRAINS CLASSIC/MISTIC 16-CHANNEL ANALOG

DATA SHEET

Form 730-050728

page 4/10


Specifications

General

Operating Specifications

Power Requirements	5.0 VDC \pm 0.1 VDC @ 600 mA max. (supplied through header connector pins 1 and 49).
Operating Temperature	0° to 70°C, 95% humidity, non-condensing
CPU	16-bit Intel 80C196 I/O processor
Communications Interface	RS-485 twisted pair with shield, 2-wire or 4-wire (if using interrupts)
Data Rates	300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 76800, and 115200 baud
Range: Multidrop	Unlimited. (Up to 3,000 feet or 32 stations maximum between repeaters)
PID Update Rate	100 ms (for 1 to 8 PID loops)
LED Indicators	RUN (Power On), RCV (Receive), XMT (Transmit), and (IRQ) Interrupt
Options: Jumper Selectable	Address, communication, baud rate, CRC/Checksum, Binary/ASCII

Connectors and Jumpers



Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • Phone: (951) 695-3000 • (800) 321-OPTO • Fax: (951) 695-3095 • www.opto22.com