








Model Number

NCN4-12GM40-E2-3G-3D

Features

- 4 mm not embeddable
- ATEX-approval for zone 2 and zone 22


Connection



Accessories

BF 12 Mounting flange, 12 mm

Dimensions



Technical Data

1001111041 2414					
	General specifications				
	Switching element function		PNP	NO	
	Rated operating distance	s _n	4 mm		
	Installation		not embeddable		
	Output polarity		DC		
	Assured operating distance	sa	0 3.24 mm		
	Reduction factor r _{Al}		0.37		
	Reduction factor r _{Cu}		0.36		
	Reduction factor r ₃₀₃		0.74		
Nominal ratings					
	Operating voltage	U _B	10 30 V I		
	Switching frequency	f	0 1200 H		
	Hysteresis	Н	1 10 typ.	0.3 %	
	Reverse polarity protected			larity protected	
	Short-circuit protection		pulsing		
	Voltage drop	U_d	≤ 3 V		
	Operating current	ΙL	0 200 m/	iA .	
	No-load supply current	I ₀	≤ 15 mA		
	Indication of the switching state		LED, yellow	W	
Ambient conditions					
	Ambient temperature			C (-13 158 °F)	
	Storage temperature		-40 85 °C	C (-40 185 °F)	
Mechanical specifications					
	Connection type		cable PVC	; , 2 m	
	Core cross-section		0.34 mm ²		
	Housing material		Stainless st	steel	
	Sensing face		PBT		
	Protection degree		IP67		
General information					
	Use in the hazardous area		see instruct	ction manuals	
	Category		3G; 3D		

Category Compliance with standards and directives

Standard conformity

EN 60947-5-2:2007 Standards

IEC 60947-5-2:2007

Approvals and certificates

UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose
CCC approval	Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

Pepperl+Fuchs Group www.pepperl-fuchs.com

ATEX 3G (nA)

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n" Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load

short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

Maximum permissible ambient tempera-

ture T_{Umax}

dependant of the load current I_L and the max. operating voltage $U_{\mbox{\footnotesize Bmax}}$ Information can be taken from the following list.

at U_{Bmax} =30 V, I_{L} =200 mA 43 °C (109.4 °F) 50 °C (122 °F) at U_{Bmax} =30 V, I_{L} =100 mA 53 °C (127.4 °F) at U_{Bmax} =30 V, I_{L} =50 mA

The sensor must not be exposed to ANY FORM of mechanical danger. Protection from mechanical danger

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

211258_eng.xml Date of issue: 2011-07-19 Release date: 2011-07-19 11:21

www.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

ATEX 3D (tD)

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with combustible dust

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification ⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. Installation, Comissioning

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions The maximum permissible load current must be restricted to the values given in the following list. Maximum operating current I_I

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

dependant of the load current I_L and the max. operating voltage U_{Bmax} . Maximum permissible ambient tempera-Information can be taken from the following list.

ture T_{Umax} at U_{Bmax} =30 V, I_{L} =200 mA 43 °C (109.4 °F)

at U_{Bmax} =30 V, I_{L} =100 mA 50 °C (122 °F) at U_{Bmax} =30 V, I_{L} =50 mA 53 °C (127.4 °F)

The sensor must not be exposed to ANY FORM of mechanical danger. Protection from mechanical danger

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor Protection from UV light

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading. Protection of the connection cable

fa-info@us.pepperl-fuchs.com

www.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com