


The chipKIT™ Development Platforms are based off the PIC32 Microcontroller. These are 32-bit products that bring unprecedented features to the Arduino™ community. In order to maintain compatibility with existing hardware/software while maintaining user accessibility to these advanced features, additional jumpers and row headers are provided. This document describes the functionality of the jumpers listed in figure 1.

Figure 1: chipKIT™ Max32 Jumpers



Jumper	Function
--------	----------

JP1	<b>POWER SELECT:</b> Used to connect/bypass on-board 5V regulator when using a power supply connected to J2
-----	---



J4 supply is regulated (i.e. 5V will be present on 5V pin)



J4 supply bypasses regulator (i.e. Supply voltage will be present on 5V pin)

*Note: A 3.3V on-board regulator will always be enabled regardless of JP1 settings to protect the PIC32 MCU*

*Not sure what this does? Play it safe and keep JP1 on the two right-most pins. (i.e. J2 supply is regulated)*

## JP3/JP4

**SPI SELECT:** Used to configure the chipKIT™ as either a Master or Slave when using the SPI (Serial Peripheral Interface). The chipKIT™ board can be connected to another device or even another chipKIT™ through the SPI connector (J13).



chipKIT™ configured as a SPI Master



chipKIT™ configured as a SPI Slave



For more information on SPI, please visit Wikipedia's SPI page at:  
[http://en.wikipedia.org/wiki/Serial\\_Peripheral\\_Interface\\_Bus#Mode\\_Numbers](http://en.wikipedia.org/wiki/Serial_Peripheral_Interface_Bus#Mode_Numbers)